
SYSTEM DIAGRAM

05|12-01



DIAGNOSTICS - DOOR CLOSER SYSTEM

Sender	Receiver	Signal	Communication Line
Driver Door ECU	Theft Warning ECU	Driver door closer operating signal	BEAN
Passenger Door ECU	Theft Warning ECU	Passenger door closer operating signal	BEAN
Rear Door ECU LH	Theft Warning ECU	Rear left door closer operating signal	BEAN
Rear Door ECU RH	Theft Warning ECU	Rear right door closer operating signal	BEAN