REPLACEMENT

HINT:

- The installation procedures are the removal procedures in reverse order. However, only installation procedures requiring additional information are included.
- Apolt without a florque specification is shown in the standard bolt chart see page 03-2)
- 1. REMOVE REAR SEAT CUSHION ASSY See page 72-13)
- 2. REMOVE[REAR[\$EATBACK[ASSY](See[page[72-13])
- 3. REMOVE[ROOF[HEADLINING[ASSY[See[page[76-52]]
- (a) Remove[]he[]ear[door[scuff[plate]]LH[and[]RH.
- (b) Remove[]the[]rear[door[]opening[]trim[]weatherstrip[]LH[]and[]RH.
- (c) Remove the rear seat side cover LH and RH.
- (d) ☐ Remove The Troof [\$ide [garnish [inner]] LH [and] RH.
- (e) Remove the assist grip.
- (f) Remove[the]rear[room[lamp[LHand[RH.
- (g) Remove the vanity amp LH and RH.
- (h) Partially remove the roof headlining.


HINT:

Do[hot]remove[the]roof[headlining[completely.[Slightly]]ower[the]rear[section[of[the]roof[headlining[so[that]the]]back[window[otass[can[be]removed]]ater[in]step[7].

- 4. REMOVE PACKAGE TRAY TRIM PANEL ASSY (See page 76-52)
- (a) Remove the rear speaker grille.
- (b) Remove the center stop tamp.
- (c) Remove the package tray trim panel.
- 5. w/ Rear sunshade:

REMOVE[PACKAGE|TRAY|TRIM|PANEL|ASSY|NO.|2|(See|page|76-52)

- (a) Remove the rear speaker grille.
- (b) Remove the package tray trim panel.
- (c) Remove the center stop lamp.
- (d) Remove the package tray trim panel No. 2.



6. REMOVE BACK WINDOW MOULDING OUTSIDE UPPER

(a) Using a knife, cut off the moulding, as shown in the illustration.

NOTICE:


Be careful not to damage the vehicle body with the knife.

(b) Remove the remaining moulding.

HINT:


Make a partial cut in the moulding. Then pull and remove it by hand.

70111-01



7. REMOVE BACK WINDOW GLASS

- (a) Disconnect the connector.
- (b) From the interior, insert piano wire between the vehicle body and glass, as shown in the illustration.
- (c) Tie object that can serve as handles (for example, wooden blocks) to all wire ends.



HINT:


Apply protective tape to the outer surface of the vehicle body to prevent its surface from being scratched.

NOTICE:

- When separating the glass from the vehicle, be careful not to damage the vehicle's paint or interior / exterior ornaments.
- (d) Cut through the adhesive by pulling the piano wire around the glass.
- (e) Disengage the stoppers.
- (f) Using a suction cup, remove the glass.

NOTICE:

Leave as much adhesive on the vehicle body as possible when removing the glass.




8. CLEAN BACK WINDOW GLASS

- (a) Using a scraper, remove the damaged stoppers and adhesive sticking to the glass.
- (b) Clean the outer circumference of the glass with white gasoline.

NOTICE:

- Do not touch the glass surface after cleaning it.
- Even if using new glass, clean the glass with white gasoline.



9. CLEAN VEHICLE BODY

- (a) Clean and shape the contact surface of the vehicle body.
 - (1) Using a knife, cut away any rough adhesive on the contact surface of the vehicle body to ensure the appropriate surface shape.

NOTICE:

Be careful not to damage the vehicle body.


HINT:

Leave as much adhesive on the vehicle body as possible.

(2) Clean the contact surface of the vehicle body with a piece of shop rag saturated with cleaner.

HINT:

Even if all the adhesive has been removed, clean the vehicle body.



10. INSTALL WINDSHIELD GLASS STOPPER NO. 2


(a) Coat the installation part of the stoppers with Primer G.

NOTICE:

- Allow the primer coating to dry for 3 minutes or more.
- Throw away any leftover Primer G.
- Do not apply too much Primer G.
- (b) Install 2 new stoppers onto the glass, as shown in the illustration.

Specification:

Area	Measurement
Α	12.4 mm (0.49 in.)
В	40 mm (1.57 in.)
С	12.5 mm (0.49 in.)



11. INSTALL WINDSHIELD GLASS STOPPER NO. 1


(a) Install 2 new stoppers to the vehicle body, as shown in the illustration.

12. INSTALL BACK WINDOW MOULDING OUTSIDE UPPER

(a) Using a brush or sponge, coat the edge of the glass and the contact surface with Primer G.

NOTICE:

- Allow the primer coating to dry for 3 minutes or more.
- Throw away any leftover Primer G.
- Do not apply too much Primer G.
- (b) Install the moulding.



13. INSTALL BACK WINDOW GLASS

- (a) Position the glass.
 - (1) Using a suction cup, place the glass in the correct position.
 - (2) Check that the whole contact surface of the glass rim is perfectly even.
 - (3) Place reference marks between the glass and vehicle body.


NOTICE:

Check that the stoppers are attached to the vehicle body correctly.

HINT:

When reusing the glass, check and correct the reference mark positions.


(4) Remove the glass.



(b) Using a brush, coat the exposed part of the vehicle body with Primer M.

NOTICE:

- Allow the primer coating to dry for 3 minutes or more.
- Do not coat the adhesive with Primer M.
- Throw away any leftover Primer M.
- Do not apply too much Primer M.



(c) Using a brush or sponge, coat the edge of the glass and the contact surface with Primer G.

HINT:


If an area other than that specified is coated by accident, wipe off the primer with a clean shop rag before it dries.

NOTICE:

- Allow the primer coating to dry for 3 minutes or more.
- Throw away any leftover Primer G.
- Do not apply too much Primer G.

(d) Apply adhesive.

Adhesive: Part No. 08850-00801 or equivalent



(1) Cut off the tip of the cartridge nozzle, as shown in the illustration.

HINT:

After cutting off the tip, use all adhesive within the time described in the table below.


Usage timeframe:

Temperature	Usage Timeframe
35°C (95°F)	15 minutes
20°C (68°F)	1 hour 40 minutes
5°C (41°F)	8 hours

- (2) Load the sealer gun with the cartridge.
- (3) Coat the glass with adhesive, as shown in the illustration.

Specification:


Area	Measurement
а	12.5 mm (0.49 in.)
b	8 mm (0.31 in.)
С	6.5 mm (0.26 in.)



- (e) Install the glass.
 - (1) Using a suction cup, position the glass so that the reference marks are aligned. Press it in gently along the rim.

NOTICE:

- Allow the primer coating to dry for 3 minutes or more.
- Check that the stoppers are attached to the vehicle body correctly.
- Check that the vehicle body and glass have a small gap between them.
 - (2) Lightly press the front surface of the glass to ensure that the glass is securely fit to the vehicle body.



(3) Using a scraper, remove any excess or protruding adhesive.

HINT:

Apply adhesive onto the glass rim.

NOTICE:

Do not drive the vehicle for the amount of time described in the table below.

Minimum time:

Temperature	Minimum time prior to driving vehicle
35°C (95°F)	1 hour 30 minutes
20°C (68°F)	5 hours
5°C (41°F)	24 hours

14. CHECK FOR LEAKS AND REPAIR

- (a) Conduct a leak test after the adhesive has completely hardened.
- (b) Seal any leaks with auto glass sealer.