05HYT-01

CUSTOMIZE PARAMETERS

HINT:

The following items can be customized.

NOTICE:

- After confirming whether the items requested by the customer are applicable or not for customization, perform customize operations.
- Be sure to record the current settings before customizing.
- When troubleshooting, make sure that the item in question is not set to "OFF" as a result of customization.

Theft warning ECU:

Display (Item)	Default	Contents	Setting
UNLK/KEY TWICE (Unlock w/ 2 times D key operation)	ON	Function that unlocks only driver side door when driver side door key cylinder is turned to unlock once and unlocks all the doors when it is turned to unlock twice. In OFF setting, turning it onceunlocks all doors.	ON/OFF
UNLOCK/PARK (Unlock w/ IG ON, shift P, speed 0 km/h (0 mph))	OFF	Function that unlocks doors when lever is shifted to P position from any position other than P while the ignition switch is ON.	ON/OFF
AUTO LOCK (ONCE) (Auto Lock (ONCE))	OFF	Function that locks the doors once when the vehicle speed reaches a certain level.	ON/OFF