


# Lab – Troubleshooting Advanced Single-Area OSPFv2

# Topology



### **Addressing Table**

Device	Interface	IP Address	Subnet Mask	Default Gateway
R1	G0/0	192.168.1.1	255.255.255.0	N/A
	S0/0/0 (DCE)	192.168.12.1	255.255.255.252	N/A
	S0/0/1	192.168.13.1	255.255.255.252	N/A
R2	Lo0	209.165.200.225	255.255.255.252	N/A
	S0/0/0	192.168.12.2	255.255.255.252	N/A
	S0/0/1 (DCE)	192.168.23.1	255.255.255.252	N/A
R3	G0/0	192.168.3.1	255.255.255.0	N/A
	S0/0/0 (DCE)	192.168.13.2	255.255.255.252	N/A
	S0/0/1	192.168.23.2	255.255.255.252	N/A
PC-A	NIC	192.168.1.3	255.255.255.0	192.168.1.1
PC-C	NIC	192.168.3.3	255.255.255.0	192.168.3.1

### **Objectives**

Part 1: Build the Network and Load Device Configurations

Part 2: Troubleshoot OSPF

# **Background / Scenario**

OSPF is a popular routing protocol used by businesses worldwide. A Network Administrator should be able to isolate OSPF issues and resolve those issues in a timely manner.

In this lab, you will troubleshoot a single-area OSPFv2 network and resolve all issues that exist.

**Note**: The routers used with CCNA hands-on labs are Cisco 1941 Integrated Services Routers (ISRs) with Cisco IOS Release 15.2(4)M3 (universalk9 image). Other routers and Cisco IOS versions can be used. Depending on the model and Cisco IOS version, the commands available and output produced might vary from what is shown in the labs. Refer to the Router Interface Summary Table at the end of this lab for the correct interface identifiers.

**Note**: Make sure that the routers have been erased and have no startup configurations. If you are unsure, contact your instructor.

# **Required Resources**

- 3 Routers (Cisco 1941 with Cisco IOS Release 15.2(4)M3 universal image or comparable)
- 3 PCs (Windows 7, Vista, or XP with terminal emulation program, such as Tera Term)
- Console cables to configure the Cisco IOS devices via the console ports
- Ethernet and serial cables, as shown in the topology

# Part 1: Build the Network and Load Device Configurations

In Part 1, you will set up the network topology and configure basic settings on the PC hosts and routers.

- Step 1: Cable the network as shown in the topology.
- Step 2: Configure PC hosts.

#### Step 3: Load router configurations.

Load the following configurations into the appropriate router. All routers have the same passwords. The privileged EXEC password is **class**. The password for console and vty lines is **cisco**.

#### **Router R1 Configuration:**

```
conf t
hostname R1
enable secret class
no ip domain lookup
interface GigabitEthernet0/0
 ip address 192.168.1.1 255.255.255.0
 duplex auto
 speed auto
 no shut
interface Serial0/0/0
 bandwidth 128
 ip address 192.168.12.1 255.255.255.252
 ip ospf message-digest-key 1 md5 MD5LINKS
 clock rate 128000
 no shut
interface Serial0/0/1
 bandwidth 64
 ip ospf message-digest-key 1 md5 MD5LINKS
 ip address 192.168.13.1 255.255.255.252
 no shut
router ospf 1
 auto-cost reference-bandwidth 1000
 area 0 authentication message-digest
 passive-interface g0/0
 network 192.168.1.0 0.0.0.255 area 0
 network 192.168.12.0 0.0.0.3 area 0
 network 192.168.13.0 0.0.0.3 area 0
banner motd ^
  Unauthorized Access is Prohibited!
line con 0
 password cisco
 logging synchronous
 login
line vty 0 4
 password cisco
 login
```

```
transport input all
end
```

## **Router R2 Configuration:**

```
conf t
hostname R2
enable secret class
no ip domain lookup
interface Loopback0
 ip address 209.165.200.225 255.255.252
interface Serial0/0/0
 bandwidth 182
 ip ospf message-digest-key 1 md5 MD5LINKS
 ip address 192.168.12.2 255.255.255.252
 no shut
interface Serial0/0/1
 bandwidth 128
 ip ospf message-digest-key 1 md5 MD5LINKS
 ip address 192.168.23.1 255.255.255.252
 clock rate 128000
 no shut
router ospf 1
 router-id 2.2.2.2
 auto-cost reference-bandwidth 1000
 area 0 authentication message-digest
 passive-interface g0/0
 network 192.168.12.0 0.0.0.3 area 0
 network 192.168.23.0 0.0.0.3 area 0
ip route 0.0.0.0 0.0.0.0 Loopback0
banner motd ^
  Unauthorized Access is Prohibited!
line con 0
password cisco
 logging synchronous
 login
line vty 0 4
 password cisco
 login
 transport input all
```

#### **Router R3 Configuration:**

```
conf t
hostname R3
enable secret class
```

```
no ip domain lookup
interface GigabitEthernet0/0
 ip address 192.168.3.1 255.255.255.0
 duplex auto
 speed auto
 no shut
interface Serial0/0/0
 bandwidth 128
 ip ospf message-digest-key 1 md5 MD5LINKS
 ip address 192.168.13.2 255.255.255.252
 clock rate 128000
 no shut
interface Serial0/0/1
 bandwidth 128
 ip address 192.168.23.2 255.255.255.252
 no shut
router ospf 1
 router-id 3.3.3.3
 area 0 authentication message-digest
 passive-interface q0/0
 network 192.168.3.0 0.0.0.255 area 0
 network 192.168.13.0 0.0.0.3 area 0
 network 192.168.23.0 0.0.0.3 area 0
banner motd ^
  Unauthorized Access is Prohibited!
line con 0
 password cisco
 logging synchronous
 login
line vty 0 4
 password cisco
 login
 transport input all
end
```

#### Step 4: Test end-to-end connectivity.

All interfaces should be up and the PCs should be able to ping the default gateway.

#### Part 2: Troubleshoot OSPF

In Part 2, verify that all routers have established neighbor adjacencies, and that all network routes are available.

#### **Additional OSPF Requirements:**

• Each router should have the following router ID assignments:

#### Lab - Troubleshooting Advanced Single-Area OSPFv2

- R1 Router ID: 1.1.1.1
- R2 Router ID: 2.2.2.2
- R3 Router ID: 3.3.3.3
- All serial interface clocking rates should be set at 128 Kb/s and a matching bandwidth setting should be available to allow OSPF cost metrics to be calculated correctly.
- The 1941 routers have Gigabit interfaces, so the default OSPF reference bandwidth should be adjusted to allow cost metrics to reflect appropriate costs for all interfaces.
- OSPF should propagate a default route to the Internet. This is simulated by using Loopback interface 0 on R2.
- All interfaces advertising OSPF routing information should be configured with MD5 authentication, using MD5LINKS as the key.

List the commands used during your OSPF troubleshooting process:

List the changes made to resolve the OSPF issues. If no problems were found on the device, then respond with "no problems were found".

#### R1 Router:

#### R2 Router:

#### R3 Router:

#### Reflection

How would you change the network in this lab so all LAN traffic was routed through R2?

### **Router Interface Summary Table**

Router Interface Summary						
Router Model	Ethernet Interface #1	Ethernet Interface #2	Serial Interface #1	Serial Interface #2		
1800	Fast Ethernet 0/0 (F0/0)	Fast Ethernet 0/1 (F0/1)	Serial 0/0/0 (S0/0/0)	Serial 0/0/1 (S0/0/1)		
1900	Gigabit Ethernet 0/0 (G0/0)	Gigabit Ethernet 0/1 (G0/1)	Serial 0/0/0 (S0/0/0)	Serial 0/0/1 (S0/0/1)		
2801	Fast Ethernet 0/0 (F0/0)	Fast Ethernet 0/1 (F0/1)	Serial 0/1/0 (S0/1/0)	Serial 0/1/1 (S0/1/1)		
2811	Fast Ethernet 0/0 (F0/0)	Fast Ethernet 0/1 (F0/1)	Serial 0/0/0 (S0/0/0)	Serial 0/0/1 (S0/0/1)		
2900	Gigabit Ethernet 0/0 (G0/0)	Gigabit Ethernet 0/1 (G0/1)	Serial 0/0/0 (S0/0/0)	Serial 0/0/1 (S0/0/1)		

**Note**: To find out how the router is configured, look at the interfaces to identify the type of router and how many interfaces the router has. There is no way to effectively list all the combinations of configurations for each router class. This table includes identifiers for the possible combinations of Ethernet and Serial interfaces in the device. The table does not include any other type of interface, even though a specific router may contain one. An example of this might be an ISDN BRI interface. The string in parenthesis is the legal abbreviation that can be used in Cisco IOS commands to represent the interface.