WIKIPEDIA

Voltage divider

In <u>electronics</u>, a **voltage divider** (also known as a **potential divider**) is a passive <u>linear circuit</u> that produces an output <u>voltage</u> (V_{out}) that is a fraction of its input voltage (V_{in}). **Voltage division** is the result of distributing the input voltage among the components of the divider. A simple example of a voltage divider is two <u>resistors</u> connected in <u>series</u>, with the input voltage applied across the resistor pair and the output voltage emerging from the connection between them.

Resistor voltage dividers are commonly used to create reference voltages, or to reduce the magnitude of a voltage so it can be measured, and may also be used as signal <u>attenuators</u> at low frequencies. For direct current and relatively low frequencies, a voltage divider may be sufficiently accurate if made only of resistors; where frequency response over a wide range is required (such as in an <u>oscilloscope</u> probe), a voltage divider may have capacitive elements added to compensate load capacitance. In electric power transmission, a capacitive voltage divider is used for measurement of high voltage.




Figure 1: A simple voltage divider

Contents

General case

Examples

Resistive divider Low-pass RC filter Inductive divider Capacitive divider

Loading effect

Applications

Sensor measurement High voltage measurement Logic level shifting

References

See also

External links

General case

A voltage divider referenced to ground is created by connecting two <u>electrical impedances</u> in series, as shown in Figure 1. The input voltage is applied across the series impedances Z_1 and Z_2 and the output is the voltage across Z_2 . Z_1 and Z_2 may be composed of any combination of elements such as resistors, inductors and capacitors.

If the current in the output wire is zero then the relationship between the input voltage, V_{in} , and the output voltage, V_{out} , is:

$$V_{
m out} = rac{Z_2}{Z_1 + Z_2} \cdot V_{
m in}$$

Proof (using Ohm's Law):

$$egin{aligned} V_{ ext{in}} &= I \cdot (Z_1 + Z_2) \ V_{ ext{out}} &= I \cdot Z_2 \ I &= rac{V_{ ext{in}}}{Z_1 + Z_2} \ V_{ ext{out}} &= V_{ ext{in}} \cdot rac{Z_2}{Z_1 + Z_2} \end{aligned}$$

The transfer function (also known as the divider's **voltage ratio**) of this circuit is:

$$H=rac{V_{
m out}}{V_{
m in}}=rac{Z_2}{Z_1+Z_2}$$

In general this transfer function is a complex, rational function of frequency.

Examples

Resistive divider

A resistive divider is the case where both impedances, Z_1 and Z_2 , are purely resistive (Figure 2).

Substituting $Z_1 = R_1$ and $Z_2 = R_2$ into the previous expression gives:

$$V_{
m out} = rac{R_2}{R_1 + R_2} \cdot V_{
m in}$$

If $R_1 = R_2$ then

$$V_{
m out} = rac{1}{2} \cdot V_{
m in}$$

If $V_{\text{out}} = 6V$ and $V_{\text{in}} = 9V$ (both commonly used voltages), then:

$$rac{V_{
m out}}{V_{
m in}} = rac{R_2}{R_1 + R_2} = rac{6}{9} = rac{2}{3}$$

and by solving using algebra, R_2 must be twice the value of R_1 .

To solve for R1:

$$R_1 = rac{R_2 \cdot V_{
m in}}{V_{
m out}} - R_2 = R_2 \cdot \left(rac{V_{
m in}}{V_{
m out}} - 1
ight)$$

To solve for R2:




Figure 2: Simple resistive voltage divider

$$R_2 = R_1 \cdot rac{1}{\left(rac{V_{
m in}}{V_{
m out}} - 1
ight)}.$$

Any ratio $V_{\text{out}}/V_{\text{in}}$ greater than 1 is not possible. That is, using resistors alone it is not possible to either invert the voltage or increase V_{out} above V_{in} .

Low-pass RC filter

Consider a divider consisting of a resistor and capacitor as shown in Figure 3.

Comparing with the general case, we see $Z_1 = R$ and Z_2 is the impedance of the capacitor, given by

$$Z_2 = -\mathrm{j} X_\mathrm{C} = rac{1}{\mathrm{j} \omega C} \ ,$$

where X_C is the <u>reactance</u> of the capacitor, C is the <u>capacitance</u> of the capacitor, j is the imaginary unit, and ω (omega) is the radian frequency of the input voltage.

This divider will then have the voltage ratio:

$$rac{V_{
m out}}{V_{
m in}} = rac{Z_2}{Z_1+Z_2} = rac{rac{1}{\mathrm{j}\omega C}}{rac{1}{\mathrm{j}\omega C}+R} = rac{1}{1+\mathrm{j}\omega RC} \; .$$

The product τ (tau) = RC is called the *time constant* of the circuit.

The ratio then depends on frequency, in this case decreasing as frequency increases. This circuit is, in fact, a basic (first-order) lowpass filter. The ratio contains an imaginary number, and actually contains both the amplitude and phase shift information of the filter. To extract just the amplitude ratio, calculate the <u>magnitude</u> of the ratio, that is:

$$\left|rac{V_{
m out}}{V_{
m in}}
ight| = rac{1}{\sqrt{1+(\omega RC)^2}} \; .$$

Inductive divider

Inductive dividers split AC input according to inductance:

$$V_{
m out} = rac{L_2}{L_1 + L_2} \cdot V_{
m in}$$

The above equation is for non-interacting inductors; mutual inductance (as in an autotransformer) will alter the results.

Inductive dividers split DC input according to the resistance of the elements as for the resistive divider above.

Capacitive divider

Capacitive dividers do not pass DC input.

For an AC input a simple capacitive equation is:




Figure 3: Resistor/capacitor voltage divider

$$V_{
m out} = rac{C_1}{C_1 + C_2} \cdot V_{
m in}$$

Any leakage current in the capactive elements requires use of the generalized expression with two impedances. By selection of parallel R and C elements in the proper proportions, the same division ratio can be maintained over a useful range of frequencies. This is the principle applied in compensated oscilloscope probes to increase measurement bandwidth.

Loading effect

The output voltage of a voltage divider will vary according to the electric current it is supplying to its external <u>electrical load</u>. The effective source impedance coming from a divider of $\mathbf{Z_1}$ and $\mathbf{Z_2}$, as above, will be $\mathbf{Z_1}$ in <u>parallel</u> with $\mathbf{Z_2}$ (sometimes written $\mathbf{Z_1} / / \mathbf{Z_2}$), that is: $(\mathbf{Z_1} \mathbf{Z_2}) / (\mathbf{Z_1} + \mathbf{Z_2}) = \mathbf{HZ_1}$.

To obtain a sufficiently stable output voltage, the output current must either be stable (and so be made part of the calculation of the potential divider values) or limited to an appropriately small percentage of the divider's input current. Load sensitivity can be decreased by reducing the impedance of both halves of the divider, though this increases the divider's quiescent input current and results in higher power consumption (and wasted heat) in the divider. <u>Voltage regulators</u> are often used in lieu of passive voltage dividers when it is necessary to accommodate high or fluctuating load currents.

Applications

Voltage dividers are used for adjusting the level of a signal, for bias of active devices in amplifiers, and for measurement of voltages. A <u>Wheatstone bridge</u> and a <u>multimeter</u> both include voltage dividers. A <u>potentiometer</u> is used as a variable voltage divider in the volume control of many radios.

Sensor measurement

Voltage dividers can be used to allow a microcontroller to measure the resistance of a sensor.^[1] The sensor is wired in series with a known resistance to form a voltage divider and a known voltage is applied across the divider. The microcontroller's analog-to-digital converter is connected to the center tap of the divider so that it can measure the tap voltage and, by using the measured voltage and the known resistance and voltage, compute the sensor resistance. An example that is commonly used involves a potentiometer (variable resistor) as one of the resistive elements. When the shaft of the potentiometer is rotated the resistance it produces either increases or decreases, the change in resistance corresponds to the angular change of the shaft. If coupled with a stable voltage reference, the output voltage can be fed into an analog-to-digital converter and a display can show the angle. Such circuits are commonly used in reading control knobs. Note that it is highly beneficial for the potentiometer to have a linear taper, as the microcontroller or other circuit reading the signal must otherwise correct for the non-linearity in its calculations.

High voltage measurement

A voltage divider can be used to scale down a very <u>high voltage</u> so that it can be measured by a <u>volt meter</u>. The high voltage is applied across the divider, and the divider output—which outputs a lower voltage that is within the meter's input range—is measured by the meter. High voltage resistor divider probes designed specifically for this purpose can be used to measure voltages up to 100 kV. Special high-voltage resistors are used in such probes as they must be able to tolerate high input voltages and, to produce accurate results, must have matched <u>temperature coefficients</u> and very low voltage coefficients. Capacitive divider probes are typically used for voltages above 100 kV, as the heat caused by power losses in resistor divider probes at such high voltages could be excessive.

Logic level shifting

A voltage divider can be used as a crude <u>logic level shifter</u> to interface two circuits that use different operating voltages. For example, some logic circuits operate at 5V whereas others operate at 3.3V. Directly interfacing a 5V logic output to a 3.3V input may cause permanent damage to the 3.3V circuit. In this case, a voltage divider with an output ratio of 3.3/5 might be used to reduce the 5V signal to 3.3V, to allow the circuits to interoperate without damaging the 3.3V circuit. For this to be feasible, the 5V source impedance and 3.3V input impedance must be negligible, or they must be constant and the divider resistor values must account for their impedances. If the input impedance is capacitive,



High voltage resistor divider probe.

a purely resistive divider will limit the data rate. This can be roughly overcome by adding a capacitor in series with the top resistor, to make both legs of the divider capacitive as well as resistive.

References

1. "A very quick and dirty introduction to Sensors, Microcontrollers, and Electronics" (http://www.ieec.uned.es/investigacion/Dipseil/PAC/archivos/How%20sensors%20and%20actuators%20work%20and%20how%20to%20how%20them%20up%20to%20a%20microcontroller.pdf) (PDF). Retrieved 2 November 2015.

See also

- Current divider
- DC-to-DC converter

External links

- Divider Circuits and Kirchhoff's Laws (http://www.ibiblio.org/kuphaldt/electricCircuits/DC/DC_6.html) chapter from Lessons In Electric Circuits Vol 1 DC (http://www.ibiblio.org/kuphaldt/electricCircuits/DC/index.html) free ebook and Lessons In Electric Circuits (http://www.ibiblio.org/kuphaldt/electricCircuits/) series.
- Voltage and Current Dividers: What They Are and What They Do (http://www.allaboutcircuits.com/technical-articles/voltage-and-current-dividers-what-they-are-and-what-they-do/)
- SparkFun voltage divider tutorial (https://learn.sparkfun.com/tutorials/voltage-dividers/)
- Voltage divider calculator (http://www.allaboutcircuits.com/tools/voltage-divider-calculator/)
- A Real World Voltage Divider Calculator (http://www.xarg.org/tools/voltage-divider-calculator/)
- Voltage Divider Calculator (https://www.abelectronics.co.uk/tools/resistor-voltage-divider.aspx)

Retrieved from "https://en.wikipedia.org/w/index.php?title=Voltage_divider&oldid=913610087"

This page was last edited on 2 September 2019, at 03:16 (UTC).

Text is available under the Creative Commons Attribution-ShareAlike License; additional terms may apply. By using this site, you agree to the Terms of Use and Privacy Policy. Wikipedia® is a registered trademark of the Wikimedia Foundation, Inc., a non-profit organization.