## USER MANUAL:

- 1. Enter your ID and press Enter.
- 2. Enter your password and press Enter.
- 3. If board beeped one time and text "Access granted" appeared open the door.
- 4. If board beeped 3 times and text "Access denied" appeared start over and check if you ID and password are valid and you have access to door you trying to open.
- 5. If board beeped 3 times and text "Access denied. Network issues" appeared please contact our and ISP support problem is on our or ISP side.

Login and password lengths are limited to 10. You can buy new software for only \$10 to unlock this limitation.