Energy - from order to disorder

What happens with the ordered system (zero entropy), when it at constant temperature gradually evolves to the equilibrium (some finite entropy). Does it emits the energy? Where does the delta energy goes?

That's an *excellent* and very deep question — and you're now touching on the **thermodynamic meaning** of entropy increase, energy dissipation, and the arrow of time.

Let's go step by step — this is one of those moments where everything about thermodynamics, statistical mechanics, and even information theory comes together beautifully.

1. The setup

You start with an **ordered system** (low entropy, $S_1=0$, all spins aligned).

It is in contact with a **thermal reservoir** at constant temperature T.

Then you let it **relax toward equilibrium** — meaning it gradually becomes disordered, increasing its entropy to $S_2 > 0$.

The question:

What happens energetically during this relaxation? Does it emit energy, and where does that energy go?

ullet 2. The key relation: $\Delta F = \Delta U - T \Delta S$

At constant T,

$$dF = dU - T dS$$
.

In equilibrium thermodynamics:

• The **Helmholtz free energy** F always decreases spontaneously (it's the Lyapunov function for systems at constant T and V):

$$\Delta F < 0$$
.

 This decrease in F corresponds to useful work that can no longer be extracted—the system relaxes toward equilibrium.

3. What happens to the energy

During relaxation:

- Entropy increases: $\Delta S>0$,
- · Internal energy may or may not change depending on microscopic details,
- But in all cases, $\mathbf{heat}\ Q$ is released to the reservoir.

From the first law:

$$\Delta U = Q + W$$
,

and for a system that does no mechanical work (W=0):

$$Q = \Delta U$$
.

The second law (for the total system + bath):

$$\Delta S_{\mathrm{total}} = \Delta S_{\mathrm{system}} + \Delta S_{\mathrm{bath}} \geq 0.$$

At constant T:

$$\Delta S_{
m bath} = -rac{Q}{T}.$$

So:

$$\Delta S_{
m system} - rac{Q}{T} \geq 0.$$

If the system's entropy increases ($\Delta S_{
m system}>0$), that means Q>0: heat flows from the system to the bath.

Therefore:

As the ordered system becomes disordered (entropy increases), it **releases energy as heat** to the reservoir.

The amount of heat released is:

$$Q = T\Delta S$$
,

because at constant T,

$$\Delta F = \Delta U - T\Delta S = -T\Delta S \quad (\text{if } \Delta U = 0).$$

4. Where does that energy go?

It goes into the thermal bath (environment).

Physically:

- · Microscopic degrees of freedom (spins, vibrations, etc.) randomly fluctuate,
- · The ordered state loses its constraints,
- The released energy increases the microscopic agitation of the reservoir.

So the reservoir's internal energy increases by exactly $Q=T\Delta S$, while its temperature remains (almost) constant because it's large.

5. Intuitive interpretation

Think of it this way:

- To create order, you had to **invest** TS of energy (do work).
- When the system relaxes, that stored ordering energy is released back as heat into the
 environment.
- The system "uses up" its order potential and returns to thermal equilibrium.

That's why the **free energy decreases** during spon (\downarrow) ous relaxation:

$$\Delta F = -T\Delta S < 0.$$

6. Concrete example: ordered spins relaxing

Suppose you have N non-interacting spins at $T=300\,\mathrm{K}$.

• Ordered state: $S_1 = 0$.

• Equilibrium random state: $S_2 = Nk \ln 2$.

• Entropy increase: $\Delta S = Nk\ln 2$.

• Energy released: $Q = T \Delta S = NkT \ln 2$.

For 1 mole ($N=N_A$):

$$Q = N_A kT \ln 2 = RT \ln 2 \approx 1.7 \,\mathrm{kJ/mol}.$$

So, the system emits about **1.7 kJ of heat per mole** as it relaxes from a perfectly ordered to a random configuration at 300 K.

7. The big picture analogy

Concept	Meaning	
Creating order	Requires energy input $+TS$ — doing work to constrain randomness	
Relaxation (entropy increase)	Releases energy TS — system gives up its "order potential"	
Constant temperature	Means the environment absorbs or supplies heat without changing its $\operatorname{\sf own} T$	
Direction of time	Energy flow from system to bath accompanies entropy increase — defines irreversibility	

Summary in one line:

When an ordered system (zero entropy) relaxes to equilibrium at constant temperature, it **emits** energy $Q=T\Delta S$ as heat to the environment — the energy that was previously "stored" in its ordered configuration.

what if the ordered system is isolated, no contact with bath, how does it relaxes to equilibrium

Excellent — this is **exactly** the right next question.

You're now asking:

If the ordered system is *isolated* (no contact with a reservoir, no external heat exchange), can it still "relax" to equilibrium — and if so, **how** and **what drives that process**?

The answer depends on what kind of system we're talking about, and it brings out a deep distinction between **thermodynamic equilibrium** and **statistical equilibrium** in isolated systems.

Let's unpack this very carefully.

1. Isolated system: no exchange of energy or matter

By definition:

$$\Delta U = Q + W = 0,$$

so Q=0 (no heat exchange) and W=0 (no work done by or on the surroundings).

Therefore, the **total energy** U of the system is constant.

2. Entropy in an isolated system

For an isolated system, the Second Law still applies:

$$\Delta S_{\mathrm{system}} \geq 0$$
.

But now, since there's no external reservoir, any entropy increase must come from **internal processes**.

That means:

The system can spontaneously evolve from a low-entropy microstate to a high-entropy one, provided energy remains constant — by redistributing energy *internally* among its degrees of freedom.

This is called internal equilibration or mixing.

3. Microscopic picture — redistribution, not exchange

Even if total energy is fixed, there are typically **many microstates** that correspond to the same energy E.

An initially ordered configuration occupies a **very special**, **extremely small region** of that energy surface in phase space.

Over time, if the dynamics are ergodic or chaotic,

the system's trajectory explores the accessible phase-space region corresponding to that total energy E.

That exploration causes the **macroscopic observables** (like magnetization, spatial order, etc.) to "relax" toward their equilibrium values —

not because the system exchanges energy, but because it **redistributes** energy internally among its microscopic degrees of freedom.

4. Example: isolated spin system

Let's revisit your spin example:

- Initially all spins are aligned → minimal entropy, special microstate.
- Energy $E=-N\mu B$ if B is present (or E=0 if B=0).
- Isolated → total energy constant.

Now, for non-interacting spins **without an external field**, all configurations have the same energy. So, there is *no energetic barrier* preventing reorientation.

Quantum or thermal fluctuations within the system (spin–spin couplings, small perturbations, imperfections) can cause spins to flip over time, exploring other configurations with the same total energy.

Eventually, the system becomes **maximally mixed** — all spin orientations equally probable — even though the total energy never changed.

The entropy increases because the system now occupies a much larger region of phase space consistent with that same total energy.

5. Where does the "ordering energy" go?

This is the subtle but crucial point:

- ullet In an *open* system, the energy $T\Delta S$ is *emitted as heat* to the environment.
- In an isolated system, that same energy change manifests as an internal redistribution:
 the macroscopic order parameter loses energy, which is transferred to microscopic motions (internal
 "heat").

So the total energy remains constant, but the form of energy changes:

$$E_{\text{ordered modes}} \rightarrow E_{\text{disordered internal degrees of freedom}}$$
.

You can think of this as the system "heating itself up" internally — macroscopic order transforms into microscopic kinetic agitation.

6. Entropy increase without energy change

This is precisely how **entropy** increases even when U is constant:

- · Entropy counts the number of accessible microstates at a given energy.
- The system's dynamics "spread out" in phase space, occupying more of that constant-energy surface.
- The coarse-grained description becomes more uniform hence, higher entropy.

Mathematically, the fine-grained Liouville entropy remains constant (because Hamiltonian flow preserves phase-space volume),

but the **coarse-grained entropy** — the one relevant for macroscopic observation — increases due to mixing.

7. Summary of both cases

System Type	Exchange?	What drives relaxation?	Where does $T\Delta S$ go?
Open (constant T)	Heat exchange with reservoir	Entropy increase + energy flow	Released as heat to bath
Isolated (constant U)	No exchange	Internal mixing / redistribution	Converted into internal microscopic agitation (disordered degrees of freedom)

8. Physical intuition

Think of a perfectly aligned row of spins, or an ordered lattice, as having "stored coherence." When isolated, microscopic interactions (spin–spin coupling, phonons, small perturbations) gradually **scramble** that coherence.

You don't need an external bath — just chaotic internal dynamics.

The order "melts" into microscopic disorder, even though total energy is conserved.

In other words:

The system loses *macroscopic order* but gains *microscopic disorder* — energy is conserved, entropy increases.

Summary statement

In an isolated system, relaxation toward equilibrium occurs through *internal redistribution of energy*, not through exchange with the environment.

The ordered (low-entropy) degrees of freedom lose their coherent energy, which becomes microscopic agitation of other modes.

The total energy remains constant, but the system's entropy increases as it explores a larger portion of phase space consistent with that energy.

