<u>Extrusion Reporting – Full Manual</u> (Operator)


Table of Contents

1.	Viev	v Production Order Schedule	1
2.		duction Instruction	
3.	кер	ort Production	
	3.1	Enter Order Page	2
	3.2	Report Pallet	3
	3.3	Weigh Station	3
4.	Rep	ort Scrap	5
5.	Rep	ort Down Time	5
6.		ie QC Check	
7.		r Actions	
	7.1	Shift Checkout (7:00-7:30)	7
	7.2	Switch User (Change Employee on same line)	
	7.3	Next order (Move on to next order on schedule)	
	7.4	End Order (Remove from Schedule List)	9
8.	Wei	gh Station Functions	9
	8.1	Revise Pallet	
	8.2	Reprint Label	. 11

Extrusion

1. View Production Order Schedule


This page will display the production order schedule for your current line ordered by Seq. Make sure your page is showing the correct line.






2. Production Instruction

Click on the icon to view/print production instruction.



On this page is the detailed job jacket for this production order







3. Report Production

3.1 Enter Order Page


a. Click on the 'Start' button to begin reporting for that order



b. Enter Shift, Employee ID, and where the material is coming from.




c. Check header detail (1) on top of order page. If you need to change material input, select from the drop down for 'Material Input From' (2).



3.2 Report Pallet

- (1) Click on 'New Pallet' on the left side of order page
- (2) Once a pallet is produced, to create a pallet ID, click on 'Report Production'



Once pallet ID is created, it will appear in the log in the 'Pallet List' on bottom of page. Take pallet to Weigh Station.



3.3 Weigh Station



a. Put pallet on scale. Click on 'Search by Machine'




b. Select the Product Type




c. Choose the Line # and click on 'Select'. The Pallet ID to be weighed will appear in the table below.



d. Click on that Pallet #




- e. Weigh Whole Pallet
 - (1) Click on 'Get Weight'. (Note: Gross Weight can by manually entered as well)
 - (2) Manually enter the Tare Weight for just the pallet weight itself (not including weight of product)
 - (3) Select # of labels you need, then click on 'Print' to print the labels



Extrusion Application

4. Report Scrap

- (1) Click on 'Scrap' on the left side of order page
- (2) Fill out the Scrap Code, Scrap Reason (if applicable), Note, Estimated Weight. Click on 'Scrap Submit' when complete. The created scrap will appear in the 'Scrap List' on the bottom of page.




5. Report Down Time



Machine: V	E21 Order	#: RV22112-002	Produce Schedul		746 /	3,520	Instruction :
Material Input SI10-Silo 10	From:	□ All Material O	Produce ption Total Pa		1:	3 / 61	
Prod. Code	Dimension	Color	Balance	Need Palle	ts:	48	
H120AWS1 Description:	12mm x 48" x 96		PCs / Pa	allet: 58			
			PCs / Pa	allet: 58			
Description:		1Mx4'x8'(SM)1ST	PCs / Pa				
Description:	INTEPLAST SH 12M	1Mx4'x8'(SM)1ST					

The Line's Status will be changed to 'In Down Time' in the header on the top of the page.



b. To **STOP** the clock for Down Time, click on 'Down Time End'. The system will automatically calculate the total minutes.




6. Inline QC Check




a. Click on 'Quality Check' every hour to perform a quality check on the product




b. Click on the applicable check whether you're an operator, supervisor or audit. (Supervisor & Audit will need to input Employee ID)



c. Start inputting the measurements. If the value is or is not within tolerance, it will indicate this with a or . Once complete, click on 'Next' to move to next section.



d. Indicate the surface quality check. Once complete, click 'Confirm'



 Once values are confirmed, system will indicate whether this Quality Check has passed inspection. If quality check has failed, please inform the supervisor to determine next step.




7. User Actions




7.1 Shift Checkout (7:00-7:30)


a. At end of the shift, click on 'Shift Checkout' (Only between 7:00-7:30) to get a summary of this shift's report.



b. Enter the estimated number of pieces will be produced until end of shift (7:30).




c. Print a copy for supervisor's review.




7.2 Switch User (Change Employee on same line)

Anytime there is a switch in users, you need to input new Employee ID.

a. Click on 'Switch User' to change to another employee on this line



b. Input the shift, new employee ID, and confirm material input



7.3 Next order (Move on to next order on schedule)

This is to move on to next order on the schedule

a. Click on 'Next Order' when you are ready to move on to the next order on the schedule




7.4 End Order (Remove from Schedule List)

This is to remove order from the schedule. Scheduler will review this action to decide whether to confirm ending this order or put back on the schedule.

There are 2 ways to end an order on the floor:

- a. Line's production order page: Click on 'End' next to the order you would like to end
- b. Production Order Detail Page: Click on 'End Order' to end this production order



8. Weigh Station Functions




8.1 Revise Pallet

a. Click on 'Revise Pallet'




b. Enter or Scan in Pallet #, then click 'Search'. Pallet Details will appear in box below.



c. Click on 'Go Revise'



d. Both gross weight and tare can be revised




8.2 Reprint Label

a. Click on 'Reprint Pallet'



b. Fill in the header info to filter down by Machine, Shift, or the Pallet # itself.



c. Find the label and click on 'Print'

