
# Continuous-Wave Modulation

## 2.1 Introduction

- ☐ Analog communication system
  - The most common carrier is the sinusoidal wave.



## 2.1 Introduction

- Modulation
  - A process by which some characteristic of a carrier is varied in accordance with a modulating wave (baseband signal).
- ☐ Sinusoidal Continuous-Wave (CW) modulation
  - Amplitude modulation
  - Angle modulation

## Sinusoidal carrier 2.1 Introduction Baseband signal Amplitude Modulation Frequency Modulation

## 2.2 Double-Sideband with Carrier or simply Amplitude Modulation

Carrier  $c(t) = A_c \cos(2\pi f_c)$ 

Baseband m(t)

Modulated Signal  $s(t) = A_c[1 + k_a m(t)]\cos(2\pi f_c t)$ ,

where  $k_a$  is amplitude sensitivity or modulation index

- Two required conditions on amplitude sensitivity
  - $\square$  1 +  $k_a m(t) \ge 0$ , which is ensured by  $|k_a m(t)| \le 1$ .
    - The case of  $|k_a m(t)| > 1$  is called *overmodulation*.
    - The value of  $|k_a m(t)|$  is sometimes represented by "percentage" (because it is limited by 1), and is named  $(|k_a m(t)| \times 100)\%$  modulation.
  - $\square$   $f_c >> W$ , where W is the message bandwidth.
    - Violation of this condition will cause nonvisualized envelope.


## Modulation Index and Percentage of Modulation

As stated previously, for undistorted AM to occur, the modulating signal voltage  $V_m$  must be less than the carrier voltage  $V_c$ . Therefore the relationship between the amplitude of the modulating signal and the amplitude of the carrier signal is important. This relationship, known as the *modulation index m* (also called the modulating factor or coefficient, or the degree of modulation), is the ratio

$$m = \frac{V_m}{V_c}$$

These are the peak values of the signals, and the carrier voltage is the unmodulated value.

Multiplying the modulation index by 100 gives the percentage of modulation. For example, if the carrier voltage is 9 V and the modulating signal voltage is 7.5 V, the modulation factor is 0.8333 and the percentage of modulation is  $0.833 \times 100 = 83.33$ .



Suppose that on an AM signal, the  $V_{\max(p-p)}$  value read from the graticule on the oscilloscope screen is 5.9 divisions and  $V_{\min(p-p)}$  is 1.2 divisions.


a. What is the modulation index?

$$m\frac{V_{\text{max}} - V_{\text{min}}}{V_{\text{max}} + V_{\text{min}}} = \frac{5.9 - 1.2}{5.9 + 1.2} = \frac{4.7}{7.1} = 0.662$$

b. Calculate V<sub>c</sub>, V<sub>m</sub>, and m if the vertical scale is 2 V per division. (Hint: Sketch the signal.)

$$V_c = \frac{V_{\text{max}} + V_{\text{min}}}{2} = \frac{5.9 + 1.2}{2} = \frac{7.1}{2} = 3.55 \otimes \frac{2 \text{ V}}{\text{div}}$$
 $V_c = 3.55 \times 2 \text{ V} = 7.1 \text{ V}$ 
 $V_m = \frac{V_{\text{max}} - V_{\text{min}}}{2} = \frac{5.9 - 1.2}{2} = \frac{4.7}{2}$ 
 $= 2.35 \otimes \frac{2 \text{ V}}{\text{div}}$ 
 $V_m = 2.35 \times 2 \text{ V} = 4.7 \text{ V}$ 
 $m = \frac{V_m}{V_c} = \frac{4.7}{7.1} = 0.662$ 

## 2.2 Overmodulation




☐ The modulation index should be a number between 0 and 1.
☐ If the amplitude of the modulating voltage is higher than the carrier voltage, m will be greater than 1, causing distortion of the modulated waveform.
☐ If the distortion is great enough, the intelligence signal becomes unintelligible.
Distortion of voice transmissions produces garbled, harsh, or unnatural sounds in the speaker.
Distortion of video signals produces a scrambled and inaccurate picture on a TV screen.
☐ The modulating voltage is much greater than
the carrier voltage, resulting in a condition called overmodulation.


### Preventing overmodulation is tricky.

- Normally, the amplitude of the modulating signal is adjusted so that only the voice peaks produce 100 percent modulation. This prevents overmodulation and distortion.
  - Automatic circuits called compression circuits solve this problem by amplifying the lower-level signals and suppressing or compressing the higher-level signals.
  - The result is a higher average power output level without overmodulation.
- Distortion caused by overmodulation also produces adjacent channel interference.
- Distortion produces a non sinusoidal information signal.
  - According to Fourier theory, any non sinusoidal signal can be treated as a fundamental sine wave at the frequency of the information signal plus harmonics.
  - Obviously, these harmonics also modulate the carrier and can cause interference with other signals on channels adjacent to the carrier.

## 2.2 Example of Non-Visualized Envelope



## 2.2 Example of Visualized Envelope





## 2.2 Transmission Bandwidth


$$s(t) = A_c[1 + k_a m(t)]\cos(2\pi f_c t)$$

$$\Rightarrow S(f) = \frac{A_c}{2} \left[ \delta(f - f_c) + \delta(f + f_c) \right] + \frac{k_a A_c}{2} \left[ M(f - f_c) + M(f + f_c) \right]$$

Transmission bandwidth  $B_T = 2W$ .








### 2.2 Transmission Bandwidth

- ☐ Transmission bandwidth of an AM wave
  - For positive frequencies, the highest frequency component of the AM wave equals  $f_c + W$ , and the lowest frequency component equals  $f_c W$ .
  - The difference between these two frequencies defines the transmission bandwidth B<sub>T</sub> for an AM wave.

## 2.2 Transmission Bandwidth

The condition of  $f_c > W$  ensures that the sidebands do not overlap.



#### **DEMODULATION OF AM SIGNALS**

**Demodulation**: Restoring (or recovering) the message signal from the received modulated waveform that is generally corrupted by noise


#### Types of AM detectors:

Name of detector	Type of det.	Circuit used	Suitable for
Envelope detector	Noncoherent	Diode with an RC filter	DSB, VSB
Product detector	Coherent	Analog multiplier	Every AM


#### ENVELOPE DETECTOR

- On positive half-cycle of RF input signal s(t) the diode is forward biased and the capacitor C charges up rapidly to the peak value of RF input signal
- When RF input falls below the output voltage then the diode becomes reverse-biased and the capacitor C discharges slowly through the load resistor R<sub>l</sub>
- ullet If  $\dfrac{1}{f_c} << R_l C << \dfrac{1}{W}$


then the average value of output voltage is equal to the message signal Circuit




AM wave



Demodulated output




#### Distortion in envelope detector caused by the wrong time constant



Question: Why the frequency domain was not used in the analysis of envelope detector?

Recall: Envelope detector can be used to demodulate only DSB (no distortion) and VSB (little distortion) signals

#### Method 1: Square-Law Demodulation



Square-Law Envelope Detector

$$s(t) = A_c[1 + k_a m(t)] \cos \omega_c t$$

The baseband message m(t) is a lowpass signal with cutoff frequency W, that is,  $M(\omega) = 0$  for  $|\omega| \geq W$ .

The squarer output is

$$s^{2}(t) = A_{c}^{2}[1 + k_{a}m(t)]^{2}\cos^{2}\omega_{c}t$$

$$= 0.5A_{c}^{2}[1 + k_{a}m(t)]^{2}$$

$$+ 0.5A_{c}^{2}[1 + k_{a}m(t)]^{2}\cos 2\omega_{c}t$$

- The first term on the right-hand side is a lowpass signal except that the cutoff frequency has been increased to 2W by the squaring operation.
- The second term has a spectrum centered about  $\pm 2\omega_c$ . For positive frequencies, this spectrum is confined to the interval  $(2\omega_c 2W, 2\omega_c + 2W)$ .
- The spectra for these two terms must not overlap. This requirement is met if

$$2W < 2\omega_c - 2W$$
 or  $\omega_c > 2W$ 

- $H(\omega)$  is an ideal lowpass filter with cutoff frequency 2W so that its output is  $0.5A_c^2[1+k_am(t)]^2$ .
- The square-rooter output is proportional to m(t) with a dc offset.


#### PRODUCT DETECTOR

In coherent detection or synchronous demodulation both the phase and frequency of carrier must be known at the detector. Carrier is recovered by the carrier recovery circuit at the receiver.

#### Techniques for providing the carrier signal:

- Carrier is transmitted
- 2. A pilot signal is transmitted outside the pass-band of modulated signal


Spectrum of an AM signal (Only the positive-frequency side is shown)




**Note:** Signals to be recovered are separated in the frequency domain (See frequency regions marked by curves)  $\Longrightarrow$  Filtering is used

#### Techniques for recovering the carrier signal:

1. Recovery of carrier by a band-pass filter



2. Recovery of carrier by phase-locked loop (PLL)



**Note:** The demodulator contains a carrier recovery circuit [its output is the recovered carrier  $\hat{c}(t)$ ] and a product detector (see the analog multiplier and low-pass filter)

#### Product detector

AM modulated input signal:  $s(t) = A_c f[m(t)] \cos(2\pi f_c t)$ 


Recovered carrier:  $\hat{c}(t) = A_r \cos(2\pi f_c t)$ 

Output of analog multiplier:  $\widehat{m}(t) = s(t)\widehat{c}(t) = \frac{A_cA_r}{2}f[m(t)]\left(1 + \cos[2\pi(2f_c)t]\right)$ 

Note: • The first term contains the message signal

A low-pass filter is required to suppress the sum-frequency output


Block diagram of product detector



Recovered carrier


## 2.2 Virtues of Amplitude Modulation

- ☐ AM receiver can be implemented in terms of *simple circuit* with *inexpensive electrical components*.
  - E.g., AM receiver



## 2.2 Virtues of Amplitude Modulation

The bandwidth of  $m^2(t)$  is twice of m(t). (So to speak, the bandwidth of m(f)\*m(f) is twice of m(f).)



## 2.2 Virtues of Amplitude Modulation

So if  $2f_c > 4W$ ,

$$\Rightarrow v_2(t) = \frac{A_c^2}{2} [1 + k_a m(t)]^2$$
$$\Rightarrow v_3(t) = \frac{A_c}{\sqrt{2}} [1 + k_a m(t)]$$

if 
$$m(t)$$
 is zero mean  $\Longrightarrow \frac{A_c k_a}{\sqrt{2}} m(t)$ 

By means of a squarer, the receiver can recover the information-bearing signal without the need of a local carrier.

## 2.2 Limitations of Amplitude Modulation (DSB-C)

☐ Wasteful of power and bandwidth

$$s(t) = A_c [1 + k_a m(t)] \cos(2\pi f_c t)$$


$$= \underbrace{A_c \cos(2\pi f_c t)}_{\text{with carrier}} + k_a m(t) \cos(2\pi f_c t)$$

Waste of power in the information-less "with-carrier" part.

## 2.2 Limitations of Amplitude Modulation

☐ Wasteful of power and bandwidth

Only requires half of bandwidth after modulation



## 2.3 Linear Modulation

- Definition
  - Both  $s_I(t)$  and  $s_Q(t)$  in

$$s(t) = s_I(t)\cos(2\pi f_c t) - s_Q(t)\sin(2\pi f_c t)$$

are *linear* function of m(t).

### 2.3 Linear Modulation

- For a single real-valued m(t), three types of modulations can be identified according to how  $s_Q(t)$  are *linearly* related to m(t), at the case that  $s_I(t)$  is exactly m(t):
  - □ (Some modulation may have  $m_i(t)$  and  $m_Q(t)$  that respectively bear independent information.)
  - Double SideBand-Suppressed Carrier modulation (DSB-SC)
  - 2. Single SideBand (SSB) modulation
  - 3. Vestigial SideBand (VSB) modulation

## 2.3 DSB-SC and SSB

Type of modulation	$s_I(t)$	$s_Q(t)$	
DSB-SC	m(t)	0	
SSB	m(t)	$\hat{m}(t)$	Upper side band transmission
SSB	m(t)	$-\hat{m}(t)$	Lower side band transmission


 $<sup>*\</sup>hat{m}(t)$  = Hilbert transform of m(t), which is used to completely "suppress" the other sideband.




## 2.3 DSB-SC

□ Different from DSB-C, DSB-SC s(t) undergoes a *phase reversal* whenever m(t) crosses zero.


$$s(t) = m(t)\cos(2\pi f_c t)$$





## 2.3 Coherent Detection for DSB-SC

□ For DSB-SC, we can no longer use the "envelope detector" (as used for DSB-C), in which no local carrier is required for the receiver.



## 2.3 Coherent Detection for DSB-SC

$$v(t) = A_c \cos(2\pi f_c t + \phi)s(t)$$

$$= A_c A_c \cos(2\pi f_c t)\cos(2\pi f_c t + \phi)m(t)$$

$$= \frac{1}{2} A_c A_c \cos(4\pi f_c t + \phi)m(t) + \frac{1}{2} A_c A_c \cos(\phi)m(t)$$

$$\xrightarrow{LowPass} \frac{1}{2} A_c A_c \cos(\phi)m(t),$$

$$provided f_c > W.$$

$$\frac{1}{4} A_c A_c M(0) \cos \phi$$

$$provided f_c > W.$$

## 2.3 Coherent Detection for DSB-SC


- Quadrature null effect of the coherent detector.
  - □ If  $\phi = \pi/2$  or  $-\pi/2$ , the output of coherent detector for DSB-SC is *nullified*.
- If  $\phi$  is not equal to either  $\pi/2$  or  $-\pi/2$ , the output of coherent detector for DSB-SC is simply attenuated by a factor of  $\cos(\phi)$ , if  $\phi$  is a constant, independent of time.
- However, in practice, φ often varies with time; therefore, it is necessary to have an additional mechanism to maintain the local carrier in the receiver in perfect synchronization with the local carrier in the transmitter.
- Such an additional mechanism adds the system complexity of the receiver.



# Coherent Demodulation Output

$$v_0(t) = \frac{1}{2} A_c A_c' \cos(\phi) m(t)$$


▶ To maximize  $v_0(t)$ , would like  $\phi \approx 0$ .




For  $v_0(t)$  to be proportional to m(t),  $\phi$  should be constant.

Thus, we wish to synchronize the local oscillator. Let  $A'_c = 1$  for simplicity.


#### Costas Receiver



## Costas Receiver: Coherent Demodulation




## Costas Receiver: Phase Lock Circuit




#### Costas Receiver: Phase Lock Circuit

 $\phi > 0$ : Freq of local oscillator needs to temporarily decrease





#### Costas Receiver: Phase Lock Circuit

 $\phi <$  0: Freq of local oscillator needs to temporarily increase



## Costas Receiver: In-Phase and Quadrature-Phase





$$s(t) = A_c \cos(2\pi f_c t) m(t)$$
  
$$v_I(t) = s(t) \cdot \cos(2\pi f_c t + \phi)$$

Recall

$$\cos(2\pi f_c t + \phi) = \frac{e^{j\phi}}{2} e^{j2\pi f_c t} + \frac{e^{-j\phi}}{2} e^{-j2\pi f_c t} \rightleftharpoons \frac{e^{j\phi}}{2} \delta(f - f_c) + \frac{e^{-j\phi}}{2} \delta(f + f_c)$$

$$V_{I}(f) = S(f) \star \left[ \frac{e^{j\phi}}{2} \delta(f - f_{c}) + \frac{e^{-j\phi}}{2} \delta(f + f_{c}) \right]$$

$$= \frac{e^{j\phi}}{2} S(f) \star \delta(f - f_{c}) + \frac{e^{-j\phi}}{2} S(f) \star \delta(f + f_{c})$$

$$= \frac{e^{j\phi}}{2} S(f - f_{c}) + \frac{e^{-j\phi}}{2} S(f + f_{c})$$

$$V_{I}(f) = \frac{e^{j\phi}}{2}S(f - f_{c}) + \frac{e^{-j\phi}}{2}S(f + f_{c})$$


$$= \frac{\cos(\phi) + j\sin(\phi)}{2}S(f - f_{c}) + \frac{\cos(-\phi) + j\sin(-\phi)}{2}S(f + f_{c})$$


$$= \frac{\cos(\phi) + j\sin(\phi)}{2}S(f - f_{c}) + \frac{\cos(\phi) - j\sin(\phi)}{2}S(f + f_{c})$$


$$= \frac{\cos(\phi)}{2}[S(f - f_{c}) + S(f + f_{c})] + j\frac{\sin(\phi)}{2}[S(f - f_{c}) - S(f + f_{c})]$$


$$= \frac{\sin(\phi)}{2}[S(f - f_{c}) + S(f + f_{c})] + j\frac{\sin(\phi)}{2}[S(f - f_{c}) - S(f + f_{c})]$$


for  $\phi \ll 1$ .


























$$V_{I}(f) = \frac{e^{j\phi}}{2}S(f - f_{c}) + \frac{e^{-j\phi}}{2}S(f + f_{c})$$


$$= \frac{\cos(\phi) + j\sin(\phi)}{2}S(f - f_{c}) + \frac{\cos(-\phi) + j\sin(-\phi)}{2}S(f + f_{c})$$

$$= \frac{\cos(\phi) + j\sin(\phi)}{2}S(f - f_{c}) + \frac{\cos(\phi) - j\sin(\phi)}{2}S(f + f_{c})$$


$$= \frac{\cos(\phi)}{2} \underbrace{\left[\underbrace{S(f - f_{c}) + S(f + f_{c})}_{\text{significant baseband}}\right]} + j\underbrace{\frac{\sin(\phi)}{2}}_{\text{small}}\underbrace{\left[\underbrace{S(f - f_{c}) - S(f + f_{c})}_{\text{negligible baseband}}\right]}$$

for  $\phi \ll 1$ .

The closer  $\phi$  is to zero, the more significant the baseband term of  $v_I(t)$  and vice versa.



For  $\phi$  small.



$$s(t) = A_c \cos(2\pi f_c t) m(t)$$
  
$$v_Q(t) = s(t) \cdot \sin(2\pi f_c t + \phi)$$

Recall

$$\sin(2\pi f_c t + \phi) = \frac{e^{j\phi}}{2j} e^{j2\pi f_c t} - \frac{e^{-j\phi}}{2j} e^{-j2\pi f_c t} \rightleftharpoons \frac{e^{j\phi}}{2j} \delta(f - f_c) - \frac{e^{-j\phi}}{2j} \delta(f + f_c)$$

$$V_{Q}(f) = S(f) \star \left[ \frac{e^{j\phi}}{2j} \delta(f - f_c) - \frac{e^{-j\phi}}{2j} \delta(f + f_c) \right]$$

$$= \frac{e^{j\phi}}{2j} S(f) \star \delta(f - f_c) - \frac{e^{-j\phi}}{2j} S(f) \star \delta(f + f_c)$$

$$= \frac{e^{j\phi}}{2j} S(f - f_c) - \frac{e^{-j\phi}}{2j} S(f + f_c)$$

$$V_{Q}(f) = \frac{e^{j\phi}}{2j} S(f - f_{c}) - \frac{e^{-j\phi}}{2j} S(f + f_{c})$$

$$= \frac{\cos(\phi) + j\sin(\phi)}{2j} S(f - f_{c}) - \frac{\cos(-\phi) + j\sin(-\phi)}{2j} S(f + f_{c})$$


$$= \frac{\cos(\phi) + j\sin(\phi)}{2j} S(f - f_{c}) - \frac{\cos(\phi) - j\sin(\phi)}{2j} S(f + f_{c})$$


$$= \frac{\cos(\phi)}{2j} [S(f - f_{c}) - S(f + f_{c})] + j \frac{\sin(\phi)}{2j} [S(f - f_{c}) + S(f + f_{c})]$$

$$= \frac{\cos(\phi)}{2j} [S(f - f_{c}) - S(f + f_{c})] + j \frac{\sin(\phi)}{2j} [S(f - f_{c}) + S(f + f_{c})]$$

$$= \frac{\sin(\phi)}{2j} [S(f - f_{c}) - S(f + f_{c})] + j \frac{\sin(\phi)}{2j} [S(f - f_{c}) + S(f + f_{c})]$$

for  $\phi \ll 1$ .





$$V_{Q}(f) = \frac{e^{j\phi}}{2j}S(f - f_{c}) - \frac{e^{-j\phi}}{2j}S(f + f_{c})$$


$$= \frac{\cos(\phi) + j\sin(\phi)}{2j}S(f - f_{c}) - \frac{\cos(-\phi) + j\sin(-\phi)}{2j}S(f + f_{c})$$

$$= \frac{\cos(\phi) + j\sin(\phi)}{2j}S(f - f_{c}) - \frac{\cos(\phi) - j\sin(\phi)}{2j}S(f + f_{c})$$

$$= \frac{\cos(\phi)}{2j}\underbrace{\left[\underbrace{S(f - f_{c}) - S(f + f_{c})}_{\text{negligible baseband}}\right]} + j\underbrace{\frac{\sin(\phi)}{2j}}_{\text{small}}\underbrace{\left[\underbrace{S(f - f_{c}) + S(f + f_{c})}_{\text{significant baseband}}\right]}$$

for  $\phi \ll 1$ .


The closer  $\phi$  is to zero, the more negligible the baseband term of  $v_Q(t)$  and vice versa.




For  $\phi$  small.

#### Costas Receiver: $v_I(t)$ and $v_Q(t)$ $A_c \cos(2\pi f_c t) \cos(2\pi f_c t + \phi) m(t)$ spectrum $= \frac{A_c}{2}\cos(4\pi f_c t + \phi)m(t) + \frac{A_c}{2}\cos(\phi)m(t)$ Demodulated Product Low-pass Signal $v_{i}(t)$ Modulator filter $v_{o}(t)$ $\cos(2\pi f_c t + \phi)$ Voltage-controlled Phase Oscillator Discriminator DSB-SC wave $A_c \cos(2\pi f_c t) m(t)$ spectrum -90 degree Phase Shifter $\sin(2\pi f_c t + \phi)$ $v_{o}(t)$ Product Low-pass Modulator Filter $A_c \cos(2\pi f_c t) \sin(2\pi f_c t + \phi) m(t)$ $= \frac{A_c}{2} \sin(4\pi f_c t + \phi) m(t) + \frac{A_c}{2} \sin(\phi) m(t)$ spectrum


# Costas Receiver: $v_I(t)$ and $v_Q(t)$




# Costas Receiver: $v_I(t)$ and $v_Q(t)$



## Costas Receiver: Low-Pass Filter



## Costas Receiver: Local Oscillator Control



## Costas Receiver: Phase Discriminator

Two components in sequence:

(1) multiplier

$$v_0(t) \cdot v_0'(t) = \frac{A_c}{2} \cos(\phi) m(t) \cdot \frac{A_c}{2} \sin(\phi) m(t)$$

$$= \frac{A_c^2}{4} \underbrace{\cos(\phi) \sin(\phi)}_{\approx 1} m^2(t)$$

$$= \frac{A_c^2}{4} \phi m^2(t)$$

for  $\phi \ll 1$ .

#### Costas Receiver: Phase Discriminator

Two components in sequence:


(2) time-averaging unit

$$g(t) = \frac{1}{2T} \int_{-T}^{T} \frac{A_c^2}{4} \phi m^2(t) dt$$

$$= \frac{A_c^2}{4} \phi \qquad \frac{1}{2T} \int_{-T}^{T} m^2(t) dt$$
power of  $m(t)$ ; for  $T$  large is constant

Therefore, g(t) is proportional to  $\phi$ , and is the same sign as the phase error  $\phi$ .

## Costas Receiver: Voltage-controlled Oscillator



# Costas Receiver: Voltage-controlled Oscillator


If g(t) > 0 (or  $\phi > 0$ ), then the local oscillator will decrease from  $f_c$  proportional to the value of g(t) (or  $\phi$ ).


If g(t) < 0 (or  $\phi < 0$ ), then the local oscillator will increase from  $f_c$  proportional to the value of g(t) (or  $\phi$ ).

## Costas Receiver: Voltage-controlled Oscillator


temporarily decrease


 $\phi$  > 0: Freq of local oscillator needs to  $\phi$  < 0: Freq of local oscillator needs to temporarily increase





### Costas Receiver






# Multiplexing and QAM

Multiplexing: to send multiple message simultaneously

Quadrature Amplitude Multiplexing (QAM): (a.k.a quadrature-carrier multiplexing) amplitude modulation scheme that enables two DSB-SC waves with independent message signals to occupy the same channel bandwidth (i.e., same frequency channel) yet still be separated at the receiver.


## **QAM:** Transmitter



**QAM:** Transmitter

$$s(t) = A_c m_1(t) \cos(2\pi f_c t) + A_c m_2(t) \sin(2\pi f_c t)$$

## QAM: Receiver



## **QAM**: Receiver

Costas receiver may be used to synchronize the local oscillator for demodulation.