

Acme Coffee Machines - User Guide

Chapter 1: Getting Started

Unbox the machine and remove all packaging material.

Fill the water tank up to the MAX line before first use.

Chapter 2: Cleaning

Descale the machine every three months.

Use only food-safe descaling solution.