

# Release Notes



## Convert to Rinex - v4.0.1.9 - [Download Here](#)

This utility converts Trimble GNSS measurement files in DAT, T00, T01, T02, T04, RT17, RT27 or .cap format to RINEX version 2.10, 2.11, 3.02, 3.03, 3.04, 3.05 and 4.01 formats

### Bug Fixes:

- Galileo ephemeris file header format issue causing import issues with TBC
- Glonass ephemeris file header format issue causing import issues with TBC
- Removed CNAV from the navigation files when output version is Rinex 3.x or 2.x

[See Archived releases here](#)

### Command Line operation

This section describes how to use the Convert to RINEX utility from the command line.

C:\Program Files (x86)\Trimble\ConvertToRinex>convertToRinex.exe -?

USAGE:

convertToRINEX input.dat

[-p outputPath] [-r RUNBY] [-o OBSERVER] [-ag AGENCY]  
[-ac ANTENNACODE] [-an ANTENNANUMBER] [-ah HEIGHT] [-n]  
[-rc RECEIVERCODE] [-rn RECEIVERNUMBER] [-mo MARKERNAME] [-mn MARKERNUMBER])  
[-xy ApproxX,Y,Z])

[geospatial.trimble.com](https://geospatial.trimble.com)

[-v X.XX] [-k[-]] [-d] [-s] [-m] [-t] [-co] [-ca] [-ra]

[-sG] [-sR] [-sE] [-sC] [-sj] [-sl]

| @ParamFile

If run in interactive mode:

- ? Display help information.
- p Path in which to place the output files (OBS, NAV, MET, ...).
- r Run by. Person or agent performing the RINEX conversion.
- o Observer. The name of the person performing the survey.
- ag Observer's agency.
- v Output RINEX format: version X.XX. (Default = 3.04)
- ac AntennaCode. One- or two-character code (from ANTENNA.INI)
- an Antenna Number. Value to write in the NUMBER field of "ANT # / TYPE".
- ah Antenna Height. Add HEIGHT (in meters) to all antenna heights.
- n Do NOT perform default antenna height corrections.
- k First observation in the file is kinematic.
- k- Suppress all kinematic controls.
- ca Log continuous clock. Account for millisecond time steps in observations and time of observation.
- co Log Clock Offset. Include receiver clock offset values in OBS output.
- d Include Doppler values in OBS output.
- s Log SNR. Include raw signal strength values in OBS output.
- sG Strip GPS observations in OBS output.
- sR Strip Glonass observations in OBS output.
- sE Strip Galileo observations in OBS output.
- sC Strip Beidou observations in OBS output.
- sj Strip QZSS observations in OBS output.
- sl Strip IRNSS observations in OBS output.

[geospatial.trimble.com](https://geospatial.trimble.com)

- mx Mix all navigation data into one file.
- ra Include only RAIM pass data in OBS output.
- m Generate a RINEX METEOROLOGICAL file if data is present.
- t Generate a RINEX AUXiliary file containing TILT data if data is present.
- mo Marker Name. Value to write in the Obs file MARKER NAME field.
- mn Marker Number. Value to write in the Obs file MARKER NUMBER field.
- xy Marker approx XYZ.
- t4 Truncate marker name to 4 characters.
- rc Receiver Code. The receiver numeric code (from RECEIVER.INI)
- rn Receiver Number. Value to write in the NUMBER field of "REC # / TYPE / VER".

If a ParamFile is specified, it must consist of lines of the following form:

<ParameterName> = <Value>

Where <ParameterName> may be any of the following:

|         |                                                  |
|---------|--------------------------------------------------|
| DatFile | Name of DAT/T01 file to be converted.            |
| ObsFile | Name of RINEX Observation file to be created.    |
| NavFile | Name of RINEX Navigation file to be created.     |
| MetFile | Name of RINEX Meteorological file to be created  |
| RunBy   | Person or agent performing the RINEX conversion. |

[geospatial.trimble.com](https://geospatial.trimble.com)

|               |                                                             |
|---------------|-------------------------------------------------------------|
| Observer      | The name of the person performing the survey.               |
| Agency        | Observer's agency.                                          |
| RinexVersion  | Output RINEX format: version X.X. (Default = 3.04)          |
| GenMetFile    | Set to YES to enable generation of the default MET file.    |
| AntCode       | One- or two-character code (from ANTENNA.INI)               |
| AntNumber     | Value to write in the NUMBER field of "ANT # / TYPE."       |
| AntType       | AntType Value to write in the TYPE field of "ANT # / TYPE." |
| CorrToBase    | Set to NO to disable ant. ht. corr. to base of antenna.     |
| AntCorrect    | Set to NO to disable any ant. ht. Correction.               |
| AntOffset     | Vertical offset, to be added to any antenna height values.  |
| RcvrCode      | The receiver numeric code (from RECEIVER.INI)               |
| RcvrNumber    | Value to write in the NUMBER field of "REC # / TYPE / VER." |
| RcvrType      | Value to write in the TYPE field of "REC # / TYPE / VER."   |
| RcvrVersion   | Value to write in the VER. field of "REC # / TYPE / VER."   |
| HdrMarkerName | Value to install in the Obs file MARKER NAME field.         |

|                     |                                                                                           |
|---------------------|-------------------------------------------------------------------------------------------|
| HdrMarkerNumber     | Install in the Obs file MARKER NUMBER field.                                              |
| HdrMarkerXYZ        | XYZ (3) values for Obs file APPROX POSITION XYZ field.                                    |
| StripGPS            | Set to YES to strip GPS to the OBS file. Same as "-sG" command line option.               |
| StripGlonass        | Set to YES to strip Glonass to the OBS file. Same as "-sR" command line option.           |
| StripGalileo        | Set to YES to strip Galileo to the OBS file. Same as "-sE" command line option.           |
| StripBeidou         | Set to YES to strip Beidou to the OBS file. Same as "-sC" command line option.            |
| StripQZSS           | Set to YES to strip QZSS to the OBS file. Same as "-sJ" command line option.              |
| StripIRNSS          | Set to YES to strip IRNSS to the OBS file. Same as "-sI" command line option.             |
| MixedNavData        | Set to YES to mix all nav data into one file. Same as "-mx" command line option.          |
| LogOnlyRAIMpassData | Set to YES to log only RAIM pass data to the OBS file. Same as "-ra" command line option. |

|                 |                                                                                                  |
|-----------------|--------------------------------------------------------------------------------------------------|
| KinStart        | Set to YES to indicate that the antenna starts in motion.                                        |
| LogDoppler      | Set to YES to log Doppler. Same as "-d" command line option.                                     |
| LogSNR          | Set to YES to log SNR. Same as "-s" command line option.                                         |
| AddMSecOffsets  | Set to YES to include millisecond clock rollovers.                                               |
| AddRcvrOffsets  | Set to YES to include receiver-computed clock offsets.                                           |
| AdjDisabled     | Set to YES to disable adjustment of the total clock offset for the time, pseudorange, and phase. |
| AdjObservations | Set to YES to subtract the total clock offset from the time, pseudorange, and phase              |

Blank lines and all characters including and following a '#' are ignored.

Leading and trailing white space (blanks and tabs) in the <Value> field are ignored.

The default value for each of the (YES/NO) control options is the opposite of the example given above. That is, the examples above override the default.

## For more information

For more information, contact your local Trimble Distribution Partner.

[geospatial.trimble.com](https://geospatial.trimble.com)