


Host Connections


- GNSS1_PPS
nRESET
- Optional Interface: USB
USB.D_P
USB.D_N
- Optional Interface: UART or SPI
G6/Rx1/MOSI
G7/Tx1/MISO
G5/SCLK/STRBE
G8/CS/STRB
G9/SPI_EN/DRDY/STRB

SPI interface is enabled by holding G9 low during boot up.


IMX-6 INS Module




Antenna Connections




GPX-1 GNSS Module



USB Micro Connector




3.3V Supply




IG LGA Pads


Pins 1-14 assignments must match on U4 and H1





IMX-5 I/O Header



IMX-5 SWD IDC



GPX SWD IDC



CONFIDENTIAL/PROPRIETARY

Project	IMX w/ GPX Module	PCB	IS-IG-r2.1	
Sheet	Connectors	Assy	IS-IG-r2.1.0	
Date	3/31/2026	Time	6:03:21 PM	
File	C:\Users\WaltJohnson\hdw\IS-hdw\Products\IG-2\IG-2-1\Altium\Source Files\Main.SchDoc			