


"MAIN" Connector Pinout

(on Rugged side, not cable side)



Pin	Name	Direction	Description		
1	GND	-	Common ground		
2	VIN	PWR IN	4V – 20V system supply input ¹		
3	USB.VCC	PWR IN	5V system supply input ¹ from USB bus. Using this pin will enable the FTDI USB. Use the VIN pin instead to disable the FTDI USB.		
4	USB.D+	I/O	USB data positive line (Serial 0)		
5	GPS PPS	I/O	GPS time synchronization output pulse (1Hz, 10% duty cycle)		
6	USB.D-	1/0	USB data negative line (Serial 0)		
7	G3/Tx0/R85Tx1-	О	Serial 0 output (TTL or RS232) ² Serial 1 output- (RS485) ³		
8	G7/Tx1/485Tx1+/CANH	0	Serial 1 output (TTL or RS232) ³ Serial 1 output+ (RS485). CAN bus H line.		
9	G4/Rx0/485Rx1-	1	Serial 0 input (TTL or RS232) ² Serial 1 input- (RS485) ³		
10	G6/Rx1/485Rx1+/CANL	I	Serial 1 input (TTL or RS232) ³ Serial 1 input+ (RS485) ³ . CAN bus L line.		
11	G1/SDA/I2C_EN	I/O	I2C data. Hold high during power-up to enable I2C.		
12	G2/SCL/STROBE	I	I2C clock. Strobe time sync input.		

¹ The system can be powered by either VIN or USB.VCC.

³ Serial 1 is configured with SMT jumpers for TTL, RS232(default), RS485, or CAN.

UNLESS OTHERWISE SPECIFIED:		NAME	DATE	Inertial	Sense	A		
DIMENSIONS ARE IN INCHES	DRAWN	LM	4/20/2018	72 N 720 E Salem, UT 84653 Salem, UT 84653				
TOLERANCES: FRACTIONAL ± 1/8 DECIMAL .XX ±0.01 .XXX ±0.005	CHECKED	X	X	TITLE:				
ANGLES ±1°	ENG APPR.	X	X	1111	Ruggedized uINS			
DO NOT SCALE DRAWING MATERIAL	MFG APPR.	Х	Х	Pinout				
X	COMMENTS:					PINOUI		
THIRD ANGLE PROJECTION				SIZE	DWG	. NO.	REV	
\(\)				Α		IS-uINS-10	A	
⊕ - <u></u> <u>-</u> <u>-</u> <u>-</u> <u>-</u> <u>-</u> <u>-</u> <u>-</u> <u>-</u> <u>-</u> <u></u>				SCA	LE: 8:1	SH	IEET 1 OF 1	

C:\Users\Larrym\Dropbox\Projects\\S Mechanica\\Rugged uINS\CAD\d \S-uINS-10 Ruggedized uINS Pinout

5

1

PROPRIETARY AND COMPETITION SENSITIVE

THE INFORMATION CONTAINED IN THIS DOCUMENT IS THE SOLE PROPERTY OF INERTIAL SENSE. INCIDENTAL REPRODUCTION FOR THE RUD USER'S INTERNAL USE IS ALLOWED. ALL OTHER REPRODUCTION AND/OR DISSEMINATION IS PROHIBITED WITHOUT THE PRIOR WRITTEN CONSENT OF INERTIAL SENSE.

3

2

ı

² Serial 0 is configured with SMT jumpers for TTL, RS232, or FTDI USB (default, USB.D+ and USB.D-).