

SOP-CW-012 REV 1: Operation & Changeover of CW Pumps P-101 / P-102

Standard Operating Procedure SOP-CW-012 Revision: 1 Effective date: 2015-03-10
Title: Operation & Changeover of CW Pumps P-101 / P-102

PROCEDURE STEPS:

1. Confirm CT-101 basin level > 60% on local gauge.
2. Open suction valve fully; crack open discharge valve.
3. Start selected pump (P-101 duty / P-102 standby) from MCC.
4. Slowly open discharge valve; confirm PI-1101 within 3.2-3.8 kg/cm².
5. Confirm flow on FI-1102 > 420 m³/h.
6. For changeover, start standby pump first, then stop duty pump.
7. Log changeover in shift register.

HAZARDS: Rotating equipment; water hammer on fast valve operation.

Approved by: Plant Manager, Unit 4