

SOP-CW-012 REV 2: Operation & Changeover of CW Pumps P-101 / P-102

Standard Operating Procedure SOP-CW-012 Revision: 2 Effective date: 2021-09-01

Title: Operation & Changeover of CW Pumps P-101 / P-102

Supersedes: SOP-CW-012 rev 1

PROCEDURE STEPS:

1. Confirm CT-101 basin level > 60% on local gauge.
2. CHECK STR-101 DIFFERENTIAL PRESSURE: if dP > 0.4 bar, arrange strainer cleaning BEFORE pump start (added rev 2 after 2021 seal failure, ref WO-2021-0843).
3. Open suction valve fully; crack open discharge valve.
4. Start selected pump from MCC.
5. Slowly open discharge valve; confirm PI-1101 within 3.2-3.8 kg/cm².
6. Confirm flow on FI-1102 > 420 m³/h.
7. For changeover, start standby pump first, then stop duty pump.
8. Log changeover and STR-101 dP reading in shift register.

HAZARDS: Rotating equipment; water hammer; cavitation at blinded strainer.

Approved by: Plant Manager, Unit 4