

SOP-CW-012 REV 3: Operation & Changeover of CW Pumps P-101 / P-102

Standard Operating Procedure SOP-CW-012 Revision: 3 Effective date: 2025-04-15

Title: Operation & Changeover of CW Pumps P-101 / P-102

Supersedes: SOP-CW-012 rev 2

PROCEDURE STEPS:

1. Confirm CT-101 basin level > 60% on local gauge.
2. Check STR-101 differential pressure: if dP > 0.4 bar, arrange strainer cleaning before pump start.
3. MONSOON MODE (June-September): perform WEEKLY seal flush (Plan 11) verification on P-101 and P-102 - confirm flush flow at the rotameter and no blockage at the flush orifice. Added rev 3 from lessons learned in WO-2024-0912 / reliability review 2025 (R.K. Sharma).
4. Open suction valve fully; crack open discharge valve.
5. Start selected pump from MCC.
6. Slowly open discharge valve; confirm PI-1101 within 3.2-3.8 kg/cm².
7. Confirm flow on FI-1102 > 420 m³/h.
8. For changeover, start standby pump first, then stop duty pump.
9. Log changeover, STR-101 dP and (monsoon) flush verification in shift register.

HAZARDS: Rotating equipment; water hammer; cavitation at blinded strainer; seal failure spray hazard.

Approved by: Plant Manager, Unit 4