

DC circuits

Vout - turn on light


 $Vout = \left(\frac{R_2}{R_1 + R_2}\right) \times V_{\mathcal{E}}$





Strategies

Acways redraw complex systems



All current parces through bare wire

