

	Charges			
To supply labor and Sacrifier to sand existing bubbled or peeled off coating flooring				
0-300	300			
301-350				
351-400	350			
401-450	400			
451-500	450			
501-550	500			
551-600	550			
601-650	600			
651-700	650			
701-750	700			
751-800	750			
800-1200	800			
1201-1500	1000			
1501-2000	1500			
To remove & dispose existing Membrane (rorobin inclusive)		Plus (Inlcusive Rorobin)	Total	
0-300	300			
301-350			300	
351-400	350		350	
401-450	400		400	
451-500	450		450	
501-550	500		500	
551-600	550		550	
601-650	600		600	
651-700	650		650	
701-750	700	300	1000	
751-800	750	300	1050	
800-1200	800	300	1100	

1201-1500	1000	600	1600	
1501-2000	1500	600	2100	
- Plumber Service to remove and reinstall water tank				
(OPTIONAL: Owner can hire own plumber, this job required 2 trips)			Total	
1	650		650	
2	450		900	
3	400		1200	
4	350		1400	
5	300		1500	
- Plumber Service to remove and reinstall water pump				
(OPTIONAL: Owner can hire own plumber, this job required 2 trips)				
1	200			
2	300			
- To supply labor and equipment to remove and reinstall AC				
1	300			
2	550			
To supply & deliver Scaffolding				
5 sets	850			
(Existing Tiles Flooring, Additional Layer required @ rm2/sqft)	10.5 per sqft			
Normal	8.5 per sqft			
To apply two layer elastomeric coating on the designated area	500			

- To supply labors and materials to do E-Gel Injection on toilet 3 Yrs Warranty Non Hacking & Non Dusty Solution Required 3 days toilet floor dry before application Minimal Disruption: Application done within a day Resume normal use of toilet 1 hour after application				
unit	1,800			
Others				
- External Wall Crack Repair Treatment w/f Abseiling (Spiderman Service) (Warranty : 24 months)				
- Wall Crack Repair Works 1. To carry out grooving along all identified wall cracks to ensure proper bonding of repair materials. 2. To apply L-crack filler to all prepared cracks to seal and restore the affected areas. 3. To provide labour to apply liquid waterproofing membrane (2 coats) to all wall surfaces.			spiderman service	
- Flexi Cementitious Clean and prepare surface; remove dust, oil, and loose particles. Repair cracks and defects; dampen substrate to SSD condition. Angle fillet on surrounding edge of the area. Apply 1st layer evenly by brush/roller and allow to cure. Apply 2nd layer perpendicular to the first coat. Ensure full coverage at corners, joints, and upturn areas (min. 150mm).				
sqft	4.5			
Transportation Fee & Accomodation Fee	depends	Seremban: RM250		
Additional Night Work Charges @ xx%				
Solar panels				

Additional 1 layer bitumen on all joint area(special treatment for ponding test)	rm498			
24 hours Ponding test	rm500			
- PU injection To carry out PU injection (one-component system) at the beam area to seal internal cracks and effectively stop water leakage by forming a flexible, watertight barrier within the concrete structure.				
- Liquid membrane application				
- Lift Pit Repair Site Preparation • Clean and clear the lift pit area. Identify all active leakage points, cracks, honeycombs, and construction joints. Surface Preparation • Hack/roughen affected areas where necessary to expose cracks and ensure proper bonding. Mark all injection points along leakage paths. Drilling Works • Drill holes along the cracks/joints at appropriate intervals and angles to intercept water seepage pathways. Installation of Injection Packers • Install mechanical injection packers into the drilled holes to facilitate PU injection. PU Injection Works • Inject hydrophilic polyurethane grout under pressure into the cracks and voids. The PU material will react with water, expand, and form a flexible waterproof barrier to seal off leakages. Warranty • 2 Years Warranty				