RSA - Vetor de Teste

	RSA -	vetor de	leste	
	М	е	n	С
1	0	0	0	FF/Erro
2	0	0	1	0
3	0	0	2	1
4	0	0	255	1
5	0	1	0	FF/Erro
6	0	2	0	FF/Erro
7	0	255	0	FF/Erro
8	1	0	0	FF/Erro
9	2	0	0	FF/Erro
10	255	0	0	FF/Erro
11	1	1	1	0
12	1	1	2	1
13	1	1	255	1
14	1	2	1	0
15	1	255	1	0
16	2	1	1	0
17	255	1	1	0
18	2	2	2	0
19	2	2	3	1
20	2	2	255	4
21	2	3	2	0
22	2	255	2	0
23	3	2	2	1
24	255	2	2	1
25	100	10	25	0
26	59	65	71	34
27	57	52	23	8
28	185	25	51	32
29	72	154	17	16
30	98	197	115	73
31	73	21	115	98
32	104	197	115	94
33	94	21	115	104
34	2	197	115	12
35	12	21	115	2
36	113	197	115	103
37	103	21	115	113
38	112	197	115	107
39	107	21	115	112
40	255	255	255	0