

4.8 Temporary Traffic Management Requirements

4.8.1 Short Term Low Impact Setups

4.8.1.1 Works on Road – Protected by Specialist Vehicles

This practice may be used where at minimum a single lane remains operational on a multi-lane road or the works are on the shoulder and vehicles can be parked clear of the traffic lanes. Refer to AGTTM Part 5 Section 4.1 Work Protected by Specialist Vehicles and **0922-01531-STLI-001 and 002**. The works must not take longer than 1 shift in any one location.

This practice is best suited to the following tasks (does not include all tasks):

- Placement and recovery of temporary signs and barriers
- Mobile lane closures
- Progressively moving operations on multi-lane roadways
- Verge maintenance including grass mowing.
- Slow moving or stationary vehicles operating on the roadway.

This practice may be used to create a temporary speed zone, which must be terminated using a vehicle mounted speed restriction sign or VMB. A risk assessment must be provided to determine whether a temporary speed zone is appropriate and for the selection of the appropriate speed.

Where the vehicles are fitted with illuminated flashing arrow signs, they must direct traffic to one side of the vehicle where it is safe to do so. Where it is not safe to pass or overtake the work vehicle the illuminated flashing arrow should display flashing corners.

The specialist vehicle may be a shadow vehicle on low speed and low volume roads where determined appropriate by a risk assessment and must be fitted with a flashing arrow sign. In all other situations a Truck Mounted Attenuator must be used to protect the proposed worksite, particularly on high speed and high volume roads. Refer to Section 4.5.1 of this TMP for more details on where a TMA is required.

Where a shadow vehicle is used a 20-40m buffer zone must be provided between the vehicle and start of the worksite. Where a TMA is used a reference must be made to the manufacturing standards for the type of TMA, generally a 40m buffer zone must be provided. Consideration should also be provided by the Truck Mounted Attenuator driver for a lateral clearance to live traffic lanes to prevent the vehicle rolling into adjacent lanes when impacted.

4.8.1.2 Works on Road – Work Between Gaps in Traffic

This practice may be used where works are within a traffic lane and are undertaken for only a short duration between gaps of traffic. This work should be carried out where a single worker enters the road with simple tools and materials accompanied by a lookout person. Refer to AGTTM Part 5 Section 4.2 Work Between Gaps in Traffic and **0922-01531-STLI-003**. There is no duration restriction to this type of works but is dependent on whether suitable gaps of traffic can be achieved.

This practice is best suited to the following tasks (does not include all tasks):

- Removal of obstructions or debris
- Retrieving tools/equipment from the traffic side of a vehicle
- Traffic investigations
- Visual inspections on foot
- Pavement spotting and marking
- Minor pothole repairs
- Survey works
- Setup or removal of temporary signs / devices.