

The position of each vehicle in the mobile convoy must consider the impacts on vulnerable road users, particularly cyclists. The below describes the different types of vehicles within a mobile works convoy:

4.8.3.1 The Lead Vehicle

The lead vehicle provided advanced warning for road users travelling in the opposite direction to a mobile operation. Where there is poor visibility on the section of road used in the mobile convoy, the lead vehicle should advance its position to achieve a clear view for approaching vehicles. If a lead vehicle and a temporary speed zone are used, the lead vehicle must reinstate the posted speed limit. The lead vehicle is required on the following scenarios:

- Undivided two-way roads.
- For ride-on linemarking activities.
- When there are workers on foot or pedestrian type linemarking activities.

4.8.3.2 The Works Vehicle

The work vehicle is responsible for carrying out the proposed work activity or aiding workers on foot, on or adjacent to the road. The works vehicle and activity, where possible must minimise delays to traffic when in operation. Where the works involve workers on foot and there is no lead vehicle, the works vehicle must reinstate the posted speed limit. The works vehicle is not designed to protect workers on foot.

Examples of work vehicles include, but not limited to:

- Large item of plant (road marking vehicles, snow plough and graders)
- Traffic cone pick-up vehicles
- Road survey vehicles
- Mowing vehicles
- Street cleaners
- Temporary Traffic Management equipment vehicles.
- Sweepers.

4.8.3.3 The Shadow Vehicle

The shadow vehicle provides close protection to the rear of workers on foot or the work vehicles. A shadow vehicle must follow approximately 40m behind workers on foot or the works vehicle, unless otherwise stated in the manufacturers shunt distance advice. This distance should be regularly monitored to ensure that the shadow vehicle does not drive too close to the work activity, potentially causing vehicle to shunt into workers or plant, or too far from the works activity, increasing the chance of vehicles entering in front of the shadow vehicle lowering the level of protection. Where the shadow vehicle is part of a mobile convoy the driver must always remain in the cab of the vehicle. Refer to Section 4.5.1 of this document for more details on the use of shadow vehicles and the requirements of Truck Mounted Attenuators (TMA).

4.8.3.4 The Advanced Warning Vehicle

The advanced warning vehicle provides advance warning to road users coming up behind mobile works and diverting traffic past the worksite. A clear sight distance must be provided on approach to the advanced warning vehicle. Typical signage on the advanced warning vehicle includes, but is not limited to:

- Regulatory speed sign to provide speed decrease increments.
- Advanced notification of the type of works or Temporary Traffic Management setups.
- Lane status sign depicting the direction of closed lanes.
- Advanced notification of workers on foot close to live traffic lanes.