

On sections of roads where the sight distance is reduced, the advanced warning vehicle must be stopped prior to the obstruction until enough room is provided for the advanced warning distance. The driver of the advanced warning vehicle must alert workers and vehicles within the mobile convoy of any interruptions, hazards or approaching danger.

Where possible, the advanced warning vehicle should be positioned on the far left or far right, depending on the side where the works occur. The advanced warning vehicle should be positioned on the shoulder or verge and not within live traffic lanes. Where this is not practicable, use of a Truck Mounted Attenuator and positioning the advanced warning vehicle in the lane or a static setup should be considered.