

Always remember: A shadow vehicle displaying a vehicle mounted warning device (or TMA if applicable) must be used in advance of the Traffic Management Implementer's installing signs and traffic control devices to protect workers.

Note: - Under the Vehicle Standards Regulations, vehicle mounted warning devices are approved and shall not be used outside the limits of the road works.

7.2.5 Traffic Guidance Schemes Removal General (AGTTM Part 6 Field Staff – Implementation and Operation)

Removal of the TTM is usually considered more dangerous as crews may be fatigued, may be in a rush to get home, and often as traffic management is removed there may be no advanced warning to alert drivers to the presence of the workers. A risk assessment on each site should be taken into consideration prior to the removal process. As part of this assessment, what has been happening on site (during that road work period) should be also considered as it will represent the type of road user behaviours that have been observed in that location.

Considerations should include the:

- | | |
|-------------------------------|--|
| a) duration of the roadwork | e) speeds observed during road work |
| b) length of the site | f) time of day |
| c) complexity of the site | g) type of conditions (haze / sun glare etc.). |
| d) original speed of the road | |

7.2.6 Typical Removal Principles

Removal is carried out applying one of the short-term low impact provisions in accordance with AGTTM Part 5. The processes described in this section are based on limiting high risk manoeuvres during removal of the Traffic Guidance Schemes including U-Turns and loops exposing workers to live traffic without protection.

Fundamental principles that should be complied with to ensure safety during this work activity are that:

- travel should only be in a forward direction on any road
- recovery of devices must be done in the reverse order using the same work method as for setting out
- the TTM vehicle may be used as added protection considering the:
 - availability of safe park up areas near the signage placement location
 - line of sight to approaching vehicles
 - visibility of the worker and TTM vehicle to approaching vehicles
 - location of signage/devices on vehicle which need to be accessed
 - worker access to vehicle (e.g. not through crush zones)
 - available space on road shoulder or median
 - geometry/terrain of shoulder or median
 - distance between vehicle and travel path / shoulder drop off
 - Traffic Management Implementer proximity to expected travel path while traversing between vehicle and signage location
 - likely area in which the vehicle may move if impacted
 - availability of 'gaps in traffic' or lookout
- turn around procedures must be conducted in a safe and legal manner.
- Traffic Management Implementer must face the traffic when placing removing devices
- all workers must know their escape route at all times