

Where there is a change in speed limit, the minimum lane width requirements may also change with lane widths based on the applicable speed limit at that location. Changes to lane widths will apply at the change in speed limit, with the transition to the new lane width commencing at the speed limit change location. The transition to the new lane width must occur at a rate which matches the transition rate for a lateral shift (see Table 5.7) of the same distance (the lane width change) in the same location (note the 200 m value for Figure 2.2 applies to taper lengths): for example, for a lane width reduction of 0.4 m, as the lateral shift values are based on a full 3.5 m shift, the equivalent recommended lateral shift distance would be divided by approximately 8.7 ($3.5 / 0.4$) to establish the taper length required for the 0.4 m transition in lane widths.

As an example, a transition distance for a new speed limit (60 km/h) and lane width (3.0 m), from a 100 km/h zone with an existing 3.5 m lane width, will commence at the 60 km/h sign and transition the 0.5 m change in width over a distance of approximately 15 m, based on a 3.5 m lateral shift at 100 km/h being 100 m long ($100 / (3.5 / 0.5) = 14.3$).

2.6 Variations to design

Addition

Refer to Clause 1.9 of the Queensland MUTCD Part 3.

2.7 Combining different works protection methods

New

Combining different works protection methods at the one site is permitted where the requirements for the different works protection methods are met.

Within a static work site, a mobile works treatment (QGTTM Part 4) or short-term low-impact works protection methods (QGTTM Part 5) may be used when appropriate and when satisfying the risk assessment and other provisions and criteria of the different works protection methods.

As per requirements in QGTTM Part 5 Section 3.6, a static work site must not be created solely for enabling a speed reduction which would permit short-term low-impact work protection methods which require a lower speed limit than applies to be used.

When a mobile works treatment (QGTTM Part 4) or short-term low-impact works protection methods (QGTTM Part 5) are used in a static work site, the respective requirements of QGTTM Part 4 or Part 5 must be applied.