

- visibility is restricted (e.g. dust, work equipment, construction materials, abnormal weather conditions)
- limited clearance between road workers or equipment and moving traffic
- the alignment or road surface is below standard
- loose material or stones
- works can be damaged by higher speeds
- emergencies (e.g. flooding, slips, crashes, fire)
- good technical reasons (e.g. the road might otherwise collapse).

A guide to selecting the required temporary speed zone is provided in Table 5.5.