

with:

Where an excavation is readily accessible to vulnerable road users and is either likely to collect or retain water of such a depth as to constitute a danger, or is left unattended, it must be protected by one of the following:

- 6 the excavation is fully covered, fenced or backfilled when the worksite is unattended.
- 7 the excavation is covered, fenced or filled when the worksite is attended and works on the excavation are not active.
- 8 fully enclose the excavation.

Do not use barricades, traffic cones or plastic mesh fencing that is not supported by a solid frame as they are not sufficient to adequately protect vulnerable road users from excavations.

When excavations are covered with road plating, only skid resistant road plating must be used.

Difference

Replace the lead-in sentence for the list:

Table 6.1 shows clearance between an excavation, or any ground level hazard associated with the excavation, and the nearest traffic lane, relative to speed and traffic volume. The delineation method is also shown as one of three options. These are as follows:

with:

Table 6.1 defines the recommended protection method for an excavation based on clearance between an excavation or any ground level hazard associated with the excavation, and the nearest traffic lane, relative to speed and traffic volume, and depth of excavation. The protection method which should be implemented is one of the three following options: