

If any of the criteria stated previously cannot be achieved or alternative treatments detailed in this Part cannot be used, the treatments of a fully protected static worksite (see QGTTM Part 3) or mobile works convoy (see QGTTM Part 4) must be applied.

**Table 5.4.2(c) – Sight distance to the vehicle-mounted warning device**

| Speed (km/h) | Distance (m) |
|--------------|--------------|
| ≤ 45         | 80           |
| 46–55        | 100          |
| 56–65        | 120          |
| 66–75        | 140          |
| 76–85        | 160          |
| 86–95        | 180          |
| 96–105       | 200          |
| ≥ 106        | 220          |

### 5.4.3 Traffic control devices

#### New

Refer to Section 3.4 for vehicle mounted warning device requirements.

### 5.4.4 Pre-installation processes

#### New

Prior to works being conducted on site, the following checks must be undertaken:

- risk assessment must be conducted, to confirm that factors such as traffic volume and speed, road geometry and width, and the general behaviour of road users are considered when determining the appropriate traffic management arrangement
- work health and safety paperwork, such as job safety awareness forms, must be completed and signed off by the supervisor or relevant person
- if a TGS is provided, confirm TGS has been signed off by relevant personnel, with a copy of the TGS onsite at all times during the works
- appropriate personal protective equipment must be used
- all required devices / equipment must be checked and accounted for prior to leaving for site, and
- appropriate recordkeeping methods are in place.