

5.4.5 Installation (TGS instruction)

New

Short-term works outside a traffic lane do not require a TGS diagram when the works are completed in accordance with this section; however, a TGS may be developed and included in a generic TGS selection system for short-term works outside of a traffic lane activities. If provided, all signs and devices must be placed as shown on the TGS.

Before any equipment or materials are brought onto the work area, a visual check of the worksite traffic management set-up (vehicle-mounted warning devices and lookout (if required) are in place, and sight distance requirements are met) should be made in all directions, including all side roads and property accesses if required. This is to confirm that the work area is safe for all workers and road users, and signs and devices are placed as required by this section, or as indicated on the TGS (if provided).

Operation

Equipment or materials which are brought onto the work area should be unloaded from the non-traffic side of a stationary work vehicle.

The work vehicle must be located clear of traffic or parked where parking would be legal, and the safety of other road users is not compromised, and is adjacent to, or on approach (within 40 m), to the worksite in the primary direction of travel to the works if undertaking works in a single location. The work vehicle is the primary traffic management warning device for short-term works outside a traffic lane. If it is not possible to locate the work vehicle as described, for example due to inability to find an appropriate area to park the vehicle, then this works practice must not be used.

The vehicle-mounted warning device must be on at all times while work is in progress.

The lookout person (for works within 1.2 m of a traffic lane) must be positioned adjacent to the worker so that they can view approaching traffic in time to warn workers to vacate the roadway before arrival of traffic. The recommended sight distance at which the lookout person should be able to see approaching traffic is as per Table 5.4.5(a). This distance allows for the worker to respond to a warning and vacate the roadway. When using lookouts in Queensland, additional guidance and requirements for the Lookout Protection Method in the [Guideline – Traffic Management at Works on Roads](#) must be applied.

At all times when conducting these activities, the lookout person (for works within 1.2 m of a traffic lane) and worker must be within a reasonable proximity (no more than 40 m) of the vehicle with a vehicle-mounted warning device, which is parked clear of traffic lanes, and the safety of other road users is not compromised.