

About this document

This document supplements the Austroads *Guide to Temporary Traffic Management Part 6 Field Staff – Implementation and Operation*, which sets out the requirements of field staff in the process of installing, monitoring and dismantling traffic management on public roads.

How to use this document

This document is designed to be read and applied together with the Austroads *Guide to Temporary Traffic Management Part 6: Field Staff – Implementation and Operation* (AGTTM06-21 Edition 1.1). You must have access to the Guide to understand what applies in Queensland.

This document:

- sets out how AGTTM06-21 applies in Queensland
- has precedence over AGTTM06-21 when applied in Queensland
- has the same section and clause numbering and headings as AGTTM06-21.

The following table summarises the relationship between AGTTM06-21 and this document:

Applicability	Meaning
Accepted	The Guide section or clause is accepted.
Accepted, with amendments	Part or all of the section or clause has been accepted with additions, deletions or differences.
New	There is no equivalent section or clause in the Guide.
Not accepted	The Guide section or clause is not accepted.