

Figure 2.8 shows changing from STOP to SLOW.

Figure 2.8: Changing from STOP to SLOW



Source: Traffic Controller's Handbook, Eighth Edition 2014, Main Roads Western Australia

When changing the bat from STOP to SLOW:

- check the other traffic controller is showing "STOP" to his/her traffic
- check the last car has come through from the opposite direction
- check there is no machinery or trucks in the traffic lane or about to enter or turn into it
- move back to the side of the road
- re-check behind to ensure the work area is clear, check with the other traffic controller prior to sending traffic through the work area
- turn the sign to "SLOW" and signal the traffic "TO GO" with the right hand (see Section 2.9.6)
- stand clear of traffic
- remember the basic details (make, colour, etc.) of the first and the last vehicle to leave.