

There are other factors that may impact the functions of a traffic controller and the traffic controller may need to:

- be aware of job progress (including any plant or machinery operating within the site) and any problems within the work area
- communicate with the other traffic controller(s) by appropriate means
- advise the site supervisor before moving the PREPARE TO STOP sign in case other supporting signage needs to be moved with that sign or additional signage is required to support the PREPARE TO STOP.

If there are long queues, the position of the PREPARE TO STOP sign may need to be adjusted to provide adequate warning. It is not the responsibility of the traffic controller controlling traffic to move this sign. The traffic controller must notify another appropriate person on site to move the sign.

2.9.6 Two lanes, two-way roads

Where more than one traffic controller is working at a particular location, the responsibility for changing the direction of traffic flow rests with the controller who is the next to stop the traffic (this being the traffic controller who has the SLOW sign facing the traffic).

The following method must be used by traffic controllers to control traffic:

Changing from SLOW to STOP

- to stop vehicles the traffic controller must turn the bat to the STOP sign and face oncoming traffic while remaining outside the travel path (e.g. on shoulder, closed lane/s or footpath)
- the traffic controller must raise their free hand into the stop signal position with the palm towards the traffic.

Holding vehicles

- the traffic controller must continue facing the stationary vehicles and where possible allow 2-3 vehicles to stop before stepping in front of the stationary lane of traffic
- the traffic controller must be positioned approximately 6 m in front of stationary vehicles just stopped
- the traffic controller must ensure that the bat's "STOP" sign continues to face the stationary traffic.

Changing from STOP to SLOW

- to allow the stopped traffic to go slow, the traffic controller must wait until all traffic from the other end of the worksite has passed
- the traffic controller must move to the side of the road (on shoulder, closed lane/s or footpath) and clear of all traffic
- recheck the work area is still clear, check with the other traffic controller prior to sending traffic through work area
- the traffic controller must turn and stand in a sideways position so as all traffic can be visually monitored, then turn the bat to the "SLOW" sign
- with their free hand the traffic controller must give the TO GO signal
- to slow traffic further if required, the traffic controller must continue to show the SLOW side of the bat, and facing the traffic, give the TO SLOW signal moving their free arm up and down but not above shoulder level.