

Added T1-Q06, a 600x900 version of the ROAD WORK AHEAD sign.
See changes highlighted yellow following.

4.6 Signs and devices for work site approaches and departures

4.6.2 ROADWORK AHEAD (T1-1, TM1-1, T1-31, T1-Q06), ROADWORK X km AHEAD (T1-16)

Addition

The ROAD WORK AHEAD T1-Q06 sign (600 x 900) sign may be used in Queensland, however T1-Q06 shall only be used on narrow medians and shoulders where the standard sign T1-1 or T1-31 would not fit and would be an obstruction to traffic.

Add the ROAD WORK AHEAD T1-Q06 sign (600 x 900) to Table 4.1A:

Sign	Sign number	Size, mm
ROAD WORK AHEAD (Narrow format)	T1-Q06	600 x 900

Add the following image below Table 4.1A:



T1-Q06