

Replace:

Signs must be positioned a distance equal to that shown in Table 2.2 from the worksite or hazard (e.g. taper). Space successive signs (after the primary sign) the same distance as shown in Table 2.2 unless stated otherwise. If there is only a single advance warning sign on the approach, the sign must be positioned at double the spacing shown in Table 2.2 from the worksite or hazard.

with:

Signs must be positioned a distance equal to that shown in Table 2.2 from the worksite or hazard (e.g. taper). Space successive signs (after the primary sign) the same distance as shown in Table 2.2 unless stated otherwise. If there is only a single advance warning sign on the approach, the sign must be positioned at double the spacing shown in Table 2.2 from the worksite or hazard.

Note that sign spacing in Table 2.2 does not apply to the distance between the traffic controller and traffic control sign. Refer to AGTTM Part 7 for traffic controller guidance.

Table 2.2: Sign spacing

Speed (km/h) ^a	Distance (m)
≤55	15
≥56–65	45
≥66	Equal to the speed (km/h)

When designing spacing of advance warning signs, the speed to use in Table 2.2 must be as per Figure 2.2 rather than the intended travel speed. For example, if signs are positioned in the green zone, even when the speed changes from 110 km/h to 80 km/h, use the distance spacing which corresponds to a speed of 110 km/h in Table 2.2 for the first 200 m past the 80 km/h speed zone signs. If signs are positioned in the yellow zone, even when speed changes from 80 km/h to 60 km/h, use the distance which corresponds to a speed 80 km/h. Use 60 km/h for the blue zone and so on. In summary, always choose the higher speed limit in the first 200 m of the start of the new speed zone to ensure greater distance is provided to more accurately reflect potential travel speeds in these zones.