

Added a new section on using a combination of different work protection methods within a static work site.

2.7 Combining different work protection methods

New

Combining different works protection methods at the one site is permitted where the requirements for the different works protection methods are met.

Within a static work site, a mobile works treatment (QGTMM Part 4) or short-term low-impact works protection methods (QGTMM Part 5) may be used when appropriate and when satisfying the risk assessment and other provisions and criteria of the different works protection methods.

As per requirements in QGTMM Part 5 Section 3.6, a static work site must not be created solely for enabling a speed reduction which would permit short-term low-impact work protection methods which require a lower speed limit than applies to be used.

When a mobile works treatment (QGTMM Part 4) or short-term low-impact works protection methods (QGTMM Part 5) are used in a static work site, the respective requirements of QGTMM Part 4 or Part 5 must be applied.

Added information on the need for a signed detour route and provided a reference to new guidance in QGTMM on the need for signing a detour.

3 Around the worksite

3.4 Road Closures

Difference

Replace the dot point:

- if the worksite blocks a side road a detour should be provided (see Section 3.8)

with the following:

- not all road closures will require a detour route to be installed, Section 3.8 includes the requirements and considerations when signing a detour route and the parameters for determining the need for signing a detour route.