

5.4.4 Shuttle flow

Difference

Replace the entire Section 5.4.4 with the following:

Replace:

When using shuttle flow, the following are requirements and recommendations:

- Lane width should be reduced in accordance with Table 2.5. For further guidance on lane widths see Section 2.5.8.
- The swept path shall accommodate heavy and over-dimensional vehicles if required.
- Traffic control shall be provided at each end of the operation (see Section 5.10). Traffic control is not required if:
 - there is clear visibility past the work area and beyond it for at least 75 m, or to the end of the road if less than 75 m away
 - road users have clear visibility of the work area and the opposing approach for a distance greater than 150 m and either one of the following:
 - traffic volume in both directions is 40 vph or less, and the speed is 70 km/h or less, and the length of the single lane is 60 m or less
 - the length of the single lane is 100 m or less, and GIVE WAY and ONE LANE signs are provided at one end of the shuttle lane
 - it is a residential street and the length of the shuttle is 60 m or less.
- Ensure single lane section lengths are a maximum distance as shown in Table 5.4.

with:

This method is typically used when a portion of the roadway is closed so that a single lane is used alternately by traffic travelling in opposite directions. It is one-way flow with one direction first, then the other.

When using shuttle flow, the following are requirements and recommendations:

- Lane widths must be in accordance with Table 2.5. For further guidance on lane widths, see Section 2.5.8.
- The swept path must accommodate heavy and over-dimensional vehicles if required.
- Active traffic control (by traffic controllers or PTCs) must be provided at each end of the operation (see Section 5.10), except as follows:
 - GIVE WAY and ONE LANE signs are provided at one end of the shuttle lane and