

Entire clause now located in QGTTM to make it easier for the end user to use the document. No longer needing to go back and forth between the QGTTM and AGTTM several times.

Information which was remaining in AGTTM has been relocated to QGTTM and is highlighted blue.

See changes highlighted yellow following.

5.10 Traffic control

5.10.2 Traffic controllers

Difference

Replace the entire Section 5.10.2 with the following:

Replace:

Worksites are hazardous areas so use manual traffic control only where PTCDs are insufficient to provide the safety, capacity and efficiency required for effective traffic control. When traffic controllers are used, traffic controllers cannot direct a road user to contradict upcoming intersection signals. Traffic controllers are to coordinate activities with operating signals. If traffic controllers are operating within close proximity to a signalised intersection and the lights are flashing yellow or are off, a traffic controller must only control one lane and the approach to this intersection must be reduced to one lane of traffic. Where works cause delays to traffic flow or a side road intersects the worksite, do not use an automated PTCD, a traffic controller is required. The following requirements and recommendations apply when using traffic controllers:

with

Worksites are hazardous areas so use manual traffic control only where PTCDs are insufficient to provide the safety, capacity and efficiency required for effective traffic control. When traffic controllers are used, traffic controllers cannot direct a road user to contradict upcoming intersection signals. Traffic controllers are to coordinate activities with operating signals. If traffic controllers are operating within close proximity to a signalised intersection and the lights are flashing yellow or are off, a traffic controller must only control one lane and the approach to this intersection must be reduced to one lane of traffic. Where works cause delays to traffic flow, or a side road intersects the worksite, do not use an automated PTCD, a