

QGTTM Part 4

Added a new Section on using a combination of different work protection methods within a mobile work site.

2 Design Process

2.5 Essential Design Principles

2.5.8 Combining different works protection methods

New

Combining different works protection methods at the one mobile works site is permitted where the requirements for the different works protection methods are met.

Within a mobile works site, a static work site treatment (QGTTM Part 3) or short-term low-impact works protection methods (QGTTM Part 5) may be used when appropriate and when satisfying the risk assessment and other provisions and criteria of the different works protection methods.

When a static work site treatment (QGTTM Part 3) or short-term low-impact works protection methods (QGTTM Part 5) are used in a mobile works site, the respective requirements of QGTTM Part 3 or Part 5 must be applied.

Added default speed limit values used in Queensland and adjusted terminology for default speed limits to match other TMR documents (built-up area and not in a built-up area).

Added a new Section on using a combination of different work protection methods within a mobile work site.

See changes highlighted yellow following.