

QGTTM Part 5

Basic planning is required so that STLI is identified as best option, need to justify the use of STLI as opposed to another approach.

Removed the sentence regarding the need for a TMP and a risk assessment delivering a similar outcome.

See changes highlighted yellow following.

2 Design process

2.1 General

Addition

Note that, for Part 5 work protection methods only, a TGS could be in the form of a work method statement for short term low impact works.

~~A TMP may not be required for short-term low-impact works conducted in accordance with this Part, as the required on-site risk assessment will deliver a similar outcome.~~