

Queue Treatments the details must be provided to the Traffic Management Implementor prior to the works commencing.

4.1.7 Portable Traffic Control Devices

Portable Traffic Control Devices (PTCD) are required on all roads within the Main Roads Network with the following exclusions:

- At permanent traffic signals, based on a risk assessment.
- Where the total cumulative time of the stop-slow activity over a 24-hour period is 5 minutes or less, based on a risk assessment.
- Activities 5 to 15 minutes at a single location or multiple different work locations based on a documented risk assessment with the following;
 - A site specific Traffic Management Plan
 - A Traffic Guidance Schemes (with an authorised Traffic Management Plan) determined site suitable by a person with WTM/AWTM accreditation
- Stop / slow permitted for TTM set up and pack down.
- Emergency and Incident Management.
- In the event of failure of the PTCD's

Refer to the Main Roads Code of Practice Section 6.8.3 Portable Traffic Control Devices Page 50 Table 12 for examples of Traffic Control Scenarios that are mandatory to use PTCD's.

On all other networks a PTCD should be considered however, it is accepted that it is not always practicable to install such devices and a risk assessment should be provided prior to the works commencing. PTCDs on all other networks must be used under the following conditions however, the above exclusions may still apply:

- Roads with a permanent speed limit of 90km/h or more and over 2,000vpd
- Roads with a permanent speed limit of 70km/h or more and over 10,000vpd

Where roadside hazards or features prevent or alter the placement of PTCD's this will need to be identified and mitigated where possible, this should be identified in the planning stage. A PTCD must only be replaced with a Traffic Controller where the risk has been assessed and endorsed by an RTM. A Variation to the Standards will need to be provided for Road Infrastructure Manager endorsement.

Prior to the use of PTCDs a risk assessment should be provided which determines; duration of operation, time of setup, mitigations in the event of failure, traffic volumes, location of device and traffic speed. Refer to the Main Roads Code of Practice for the approved PTCDs for the use within the State of Western Australia.

4.1.8 Speed Management

The management of speed is a crucial contributor to a safe worksite and the chance of crashes is reduced at low traffic speeds. The Traffic Management Assessor or Delivery Supervisor must determine the requirements of speed management prior to the implementation of any devices. Where traffic speed is predicted to be high at the planning stage or where excessive speed is observed on site the following may be used to mitigate speed:

- Implementing temporary speed zones based on worker clearances and Temporary Traffic Management arrangements (traffic control).
- Roadworks pilot vehicles.
- Narrowing lane widths, chicanes and close spacing of delineation devices.