

The works vehicle placement should consider the impact on vulnerable road users including cyclists. Equipment or materials which are brought onto the work area should be unloaded from the non-traffic side of a stationary work vehicle, or the rear of a stationary work vehicle with a lookout person or shadow vehicle in place. If there are workers on foot, the work vehicle must travel immediately in front of the workers in the direction of travel.

The lookout person must be positioned adjacent to the worker so that they can view approaching traffic in time to warn the worker. Enough time must be provided to allow the worker to vacate the live traffic lanes prior to the vehicle approaching. The lookout person should ensure there is no impact on the sight distance requirements for the lookout person arising from the position of the shadow vehicle. In a frequently changing work environment, the lookout person is to move along with the workers and the works being undertaken. At all times when conducting these activities, the lookout person and worker must be within a reasonable proximity (no more than 40m) of the shadow and works vehicles, both with a vehicle mounted warning device. Recommended lookout person sight distance is shown in the table below (maximum distance of 3.5m between road workers' location and their escape path):

Table 32: AGTTM Part 5 Section 4.4.5 Table 4.8: Sight Distance for Lookout Person

Speed (km/h)	Distance (m)
≤ 45	80
46 – 55	100
56 – 65	120
66 – 75	140
76 – 85	160
86 – 95	180
96 – 110	200
>110	220

The required advanced and intermediary signs, to be erected by workers, should be done so in a manner that does not expose workers to oncoming traffic. Install signs so that the nearest edge is clear of the travelled path of vehicles and so that the signs are clearly visible to all oncoming vehicles.

4.8.1.5 Works on Road – Constantly Moving Work Area & Class 1 Mobile Convoys

This practice may be used where vehicles undertaking the works are travelling within 20km/h of the permanent speed limit (travelling 80km/h in a 100km/h speed zone or 40km/h in a 60km/h speed zone). This work can either be within the traffic lane or on an adjacent verge. Refer to AGTTM Part 5 Section 4.5 Constantly Moving Work Area – In Lane, AGTTM Part 4 Section 3.2.1 Class 1 Mobile Activities and **0922-01531-STLI-009 to 011**.

This practice is best suited to the following tasks (does not include all tasks):

- Data collection vehicles
- Mobile inspections.
- Grading.
- Monitoring traffic counts.
- Pavement testing.

Where this work practice is on high speed / volume roads within the metropolitan area, a Truck Mounted Attenuator (TMA) must be used. A TMA should be considered for all other scenarios and may be used as an option following a risk assessment. The typical Traffic Management requirements for constantly moving work areas may include advanced and intermediate warning signs, shadow vehicle and a vehicle mounted warning device on the works and shadow vehicle.