

This practice may only be used where all the criteria is met in the tables below:

**Table 37: AGTTM Part 5 Section 5.1.2 Table 5.1: Works on Shoulders, Medians, Verges and Footpaths
Workers on Foot / Small Plant**

Criteria		Yes/No
1	The work area is outside of traffic lanes.	
2	Clearance from the work area is one of the following: - If the speed is 60km/h or less, the work area does not encroach into the live traffic lane. - If the speed is more than 60km/h but equal to or less than 80km/h, the work area is at least 1.2m clear to the edge of the traffic lane. - If the speed is more than 80km/h, the work area is at least 3m clear to the edge of the traffic lane.	
3	A vehicle mounted warning device is displayed on the work vehicles, is not obscured and meets the recommended sight distance requirements table below.	

Table 38: AGTTM Part 5 Section 5.1.2 Table 5.1: Sight Distance to the Vehicle Mounted Warning Device

Speed (km/h)	Distance (m)
≤ 45	80
46 – 55	100
56 – 65	120
66 – 75	140
76 – 85	160
86 – 95	180
96 – 105	200
> 105	220

The advanced warning signs must be displayed up to 2km in advance of each work location or item of moving plant. A maximum distance of 2km between advance warning signs for opposing directions of travel must not be exceeded at any time by progressively changing their location as the work location changes. The start of the work area in relation to the advanced or intermediate warning signs in a mobile convoy must be within distances specified below:

Table 39: AGTTM Part 5 Section 2.4.2 Table 2.3: Sign Spacing

Speed (km/h)	Distance (m)
≤ 55	15
56 – 65	45
> 66	Equal to the speed (km/h)

Equipment or materials which are brought onto the work area should be unloaded from the non-traffic side of a stationary work vehicle. The required advanced warning signs, to be erected by workers, should be done so in a manner that does not expose workers to oncoming traffic. Install signs so that the nearest edge is clear of the travelled path of vehicles and so that the signs are clearly visible to all oncoming vehicles. The work vehicle should be parked, clear of any traffic lanes and adjacent to the works with the vehicle mounted device always activated.