

Where possible, the advanced warning vehicle should be positioned on the far left or far right, depending on the side where the works occur. The advanced warning vehicle should be positioned on the shoulder or verge and not within live traffic lanes. Where this is not practicable, use of a Truck Mounted Attenuator and positioning the advanced warning vehicle in the lane or a static setup should be considered.

4.8.3 Class 3 Mobile Convoys

This practice may be used where the works convoy involves workers on foot which requires the convoy to travel significantly slower than the existing speed limit. This work must be under a mobile convoy that cannot stop in live traffic lanes and small items of plant or works on foot. Refer to AGTTM Part 4 Section 3.2.3 Class 3 and **0922-01531-MS3-001** to **015**.

This practice is best suited to the following tasks (does not include all tasks):

- Linemarking using ride-on plant, self-propelled towed or pushed.
- Raised pavement marker installations
- Pedestrian type linemarking and pavement marker laying or removal where a shadow vehicle is used.

Scenarios provided in the TGS cover a single work vehicle and worker on foot on the verge to mobile convoys closing a single to multiple lanes, involving shadow, tail, and advanced warning vehicles. The scenarios provide separate mobile temporary speed zones depending on clearance between the work vehicle, workers on foot and live traffic lanes. Distances between each vehicle in the mobile works convoy, excluding the shadow vehicle, are shown in the table below:

Table 45: AGTTM Part 4 Section 3.6 Table 3.1: Spacing Distance Between Vehicles in Mobile Works

Speed (km/h)	Distance (m)
≤ 45	50
46 – 55	70
56 – 65	90
66 – 75	110
76 – 85	140
86 – 95	160
96 – 105	200
> 106	230

Any signs or devices required for the proposed works must be attached to the vehicles within the convoy. Where works are being undertaken on two-way roads, signs or devices required must be displayed on both ends of the vehicle to warn road users from the opposite direction. All vehicles within the mobile works convoy must be fitted with a vehicle mounted warning device which must not be obscured during the works.

The time taken for workers on foot to complete their tasks should be kept to an absolute minimum. All workers must be provided with communication devices allowing them to communicate with vehicles within convoy and receive notification of any approaching danger.