

3.10.2 Cyclists

Difference

Replace the sub-dot point:

- additional signage should be placed to alert road users of merging cyclists. This signage must be placed at the relevant stopping distance in advance of the closed section of the bicycle lane.

with:

- additional signage should be placed to alert road users of merging cyclists. This signage must be placed at the relevant distance (see Section 2.5.3) from the start of the closed section of the bicycle lane. Sufficient sight distance as per Table 2.3 must be provided for drivers and riders to sight the temporary signage on approach.

4 Through the worksite

4.5 Safe traffic speed

Addition

Additional guidance on supplementary devices to reduce speed is provided in the *Guideline – Traffic Management at Works on Roads*.

4.7 Traffic control and site entry

Addition

Refer to Section 4.8 of this document for the placement of the 60 km/h speed zone when the speed zone in advance of the traffic control station is above 60 kmh.

4.8 Advance warning area

Difference

Replace the entire Section 4.8 with the following:

The advance warning area is critical to the success of ‘through’ traffic management and aims to provide:

- no surprises to road users regarding traffic control
- a controlled release of relevant information (e.g. signs)
- repeated information where pertinent to emphasise danger.