

Where Police perform traffic control duties in a planned arrangement as part of a static worksite at traffic signals which are not in operation, the POLICE CONTROL AHEAD panel must be used with the Signals Not Operating (symbolic) panel in the top two 600 x 600 panels, with the POLICE CONTROL AHEAD panel positioned closest to traffic, and the 1200 x 300 version of the PREPARE TO STOP panel (see Figure 4.8.2(b)).

Figure 4.8.2(b) – Police performing traffic control duties, PREPARE TO STOP sign at signals (which are switched off or flashing amber)



4.8.3 Additional end-of-queue protection

New

Where traffic control is in use, one or a combination of end-of-queue risk control measures in Chapter 1, Clause 2 of the [Guideline – Traffic Management at Works on Roads](#) must be implemented to manage the risk of rear end crashes where either of the following apply:

- the speed limit is 80 km/h or higher (prior to any reductions for the roadworks) and an annual average daily traffic (total vehicle count in both directions of travel per day) of over 500 vehicles per day, or
- where sight-distance to the end of the traffic queue is restricted (less than the value from Table 2.3).

End-of-queue risk control measures must also be implemented when nominated in Clause 5.8 of [Annexure MRTS02.1 Provision for Traffic](#).

In addition to the requirements above, end-of-queue risk control measures should be considered and implemented to address end of queue risks at any site. Some considerations include:

- Where traffic slows significantly, or queues are formed due to congestion or roadworks.