

5.10.4 Combining portable traffic control devices

New

The Transport and Main Roads [Technical Specification](#), MRTS267 *Boom Barriers for Roadworks*, permits the use of a boom barrier with a Type-1 or Type-2 PTSS and details the technical requirements for the device.

The combination of a Type-1 or Type-2 PTSS with a boom may be used at any location a PTSS may be used but may be suited to locations where compliance with the PTSS has been poor.

The following operational requirements apply when using a combination PTSS with boom:

- The primary device will be the PTSS, with the boom providing a visual support to the operation of the signals.
- The STOP sign must not be installed on the boom.
- As the signals will be the primary device, the advance warning signs will include the signals (symbolic) panel and not the boom barrier (symbolic).
- The STOP HERE ON RED SIGNAL sign must be installed 6 m in advance of the PTSS.
- The boom must be located such that in the raised position it is slightly behind the signals (no greater than 1 m behind) and must not interfere with the visibility of the signals. Traffic stopped at the boom must still be able to see and respond to the PTSS.
- The boom may be either freestanding or attached to the same support structure as the PTSS.
- The boom in the raised position must be at least 800 mm clear of the traffic lane.
- When in the lowered position, the boom must block the approaching traffic lane and extend to a point not further than 600 mm from the road centre line.
- Four cones should be placed on the centre line spaced 4 m apart starting from the STOP HERE ON RED SIGNAL sign and extending toward approaching traffic.

The advance warning area requirements, including estimating the end of queue position and calculation requirements in Section 4.8 (including subsections), also apply to the traffic control method used in this section.

Only combination PTSS and boom barriers included on the current list of approved products in the Transport and Main Roads [ITS Approved Products](#) document must be used at roadwork sites in Queensland.