

18. a variable message sign should be used to increase visibility of warning
19. flashing lamps should be placed on barricades or fences where there is a hazard on a footpath or bicycle lane, and
20. flashing lamps should be placed on the corner of barricades or fences to ensure the roadworks site or hazard is clearly visible.

The level of lighting required must be sufficient in the work area for workers to safely conduct their duties and complete their tasks. For the traffic control station, the level of lighting must be sufficient to allow the traffic controller to see where they are going (use an escape path if required), avoid slips, trips and falls, and also illuminate the traffic control station sufficiently that it is obvious to approaching traffic.

For pedestrian areas, the level of lighting must be sufficient to illuminate any pedestrian paths so that pedestrians may avoid slips, trips and falls, and to also create a feeling of safety (personal safety) for pedestrians, with no dark (unlit or poorly lit) areas. Off- and on-road cycle paths must also be sufficiently illuminated to ensure cyclists can safely navigate and see any surface irregularities.

6.8 Excavations

Difference

Replace the following:

Where an excavation is readily accessible to any person and likely to collect or retain water of such a depth as to constitute a danger, or is left unattended, it is required that:

- the excavation is fully covered, fenced or backfilled when the worksite is unattended.
- the excavation is covered, fenced or filled when work is completed.
- only approved skid resistant plating must be used to cover an excavation.
- fully enclose the excavation. Do not use barricades, traffic cones or plastic mesh fencing that is not supported by a solid frame as they are not sufficient to adequately protect road users from excavations.