

2.5.7 Variations to Design

Addition

Refer to Clause 1.9 of the Queensland MUTCD Part 3.

2.5.8 Combining different works protection methods

New

Combining different works protection methods at the one mobile works site is permitted where the requirements for the different works protection methods are met.

Within a mobile works site, a static work site treatment (QGTMM Part 3) or short-term low-impact works protection methods (QGTMM Part 5) may be used when appropriate and when satisfying the risk assessment and other provisions and criteria of the different works protection methods.

When a static work site treatment (QGTMM Part 3) or short-term low-impact works protection methods (QGTMM Part 5) are used in a mobile works site, the respective requirements of QGTMM Part 3 or Part 5 must be applied.

3 TGS Design for Mobile Works

3.5 Step 3 – Determine the Needs of the Works Convoy

3.5.3 Shadow vehicle

Addition

In subsection **Truck mounted attenuators**, add the following sentence after the 3rd paragraph:

Only TMAs included on the current list of accepted products in the Transport and Main Roads [Accepted Road Safety Barrier Systems and Devices](#) document must be used at roadwork sites in Queensland.

3.7 Step 5 – Determine the Signs and Devices to Use

3.7.1 Advance warning

Addition

Add the following notes to Figure 3.9:

The 40 m roll ahead distance must be kept free of workers on foot and items of plant.