

Hand-held "STOP" and "SLOW" bats can be mounted back to back on a timber or aluminium pole measuring a minimum 1.8 m from the ground to the underside (bottom) of the sign.

When using the STOP / SLOW bat:

- ensure any movement of the bat (e.g. rocking slowly from side to side) does not prevent the driver from seeing it clearly
- gain the driver's attention by using hand signals and making eye contact
- hold the sign in the hand closest to traffic allowing the other hand to be free to give clear directions. This is also best in case the traffic controller is required to respond to an emergency
- take care not to inadvertently display the "STOP" or "SLOW" sign to traffic.

Warning signs

The PREPARE TO STOP sign must be used in conjunction with the Traffic Controller, Signals Ahead or Boom Barrier (symbolic) signs, and where possible these signs should be positioned side by side, with the PREPARE TO STOP sign placed closest to the travel way.

When used side by side in a multi-message situation, the PREPARE TO STOP sign must be placed closest to the travel way as a 600 x 600 sign. In this situation, the PREPARE TO STOP must not be the 1200 x 300 size as it does not demand the same authority as illustrated in Figure 2.4.

Figure 2.4: Multi-message warning sign (if sign was placed on the left hand side of the road)



2.6.4 Communication devices

Portable two-way radios or similar means will be used for communication where traffic controllers cannot see or hear each other. Additional radios with site workers may be useful to ensure that the control is suitable for the worksite. Prior to commencing any duties, the staff must ensure their radio is charged and operating correctly prior to starting any works.

When using portable two-way radios:

- ensure you know the relevant channel for the worksite (including any back up channels)
- speak clearly and slowly
- be accurate
- not use profanities or breach relevant Australian Communications and Media Authority (ACMA) or Commerce Commission of New Zealand (ComCom) communications standards
- provide enough information to allow the other traffic controller/s to know exactly what is going on