

Difference

Replace:

The ROADWORK X km AHEAD sign should be used X km in advance of a road work site, where additional advance warning is necessary.

with:

Where additional advance warning is necessary, the ROADWORK X km AHEAD sign should be used X km in advance of the Primary PREPARE TO STOP sign (if traffic control is used), or the first cone in a taper (if a taper is used), or the start of the safety buffer area, and be at least two sign spacings in advance on the ROADWORK AHEAD sign.

Clarified requirements for using the ON SIDE ROAD message including the addition of a new Figure.

Modified text to align with ON SIDE ROAD message requirements.

Added ROAD PLANT ON SIDE ROAD sign.

See changes highlighted yellow following.

4.6.7 ROADWORK ON SIDE ROAD (T1-25, TM1-25), ROAD PLANT ON SIDE ROAD (T1-27, TM1-27)

Difference

Replace:

The ROADWORK ON SIDE ROAD sign shall not be used on a side road to warn of relevant activities on the through road. The ROAD WORK AHEAD (TM1-1A) with a direction arrow (TM5-8A) should be used instead.

with:

The ROADWORK ON SIDE ROAD and ROAD PLANT ON SIDE ROAD signs shall not be used on a side road the terminating leg of a T intersection to warn of relevant activities on the through road continuing leg of the T intersection. The ROAD WORK AHEAD (TM1-1A or TM1-1C) or ROAD PLANT AHEAD (TM1-3-2C), with a direction arrow (TM5-8B) should be used instead.

The standard MMS Lane Status panel TM10-1A may be used with or without the ON SIDE ROAD message to indicate a direction where the long arrow TM5-8B is not suitable.