

Clarified that the symbolic Detour U-turn (symbolic) MMS panel must only be used with the DETOUR message.

See changes highlighted yellow following.

4.8 Detour signs

4.8.3 DETOUR (T5-1, TM5-1)

Addition

Add the following rows to Table 4.3(C):

Sign	Sign number	Size, mm
DETOUR (U-Turn)	TM5-1-Q01	DETOUR (U-Turn)
Detour (U-Turn) Symbolic	TM5-1-Q02	600 x 600
U-TURN FACILITY AHEAD	TM5-1-Q03	600 x 600

Addition

For detour routes that include a U-turn requirement, the DETOUR U-turn (TM5-1-Q01), Detour U-turn (symbolic) (TM5-1-Q02), or the U-TURN FACILITY AHEAD (TM5-1-Q03) signs may be used.

The Detour U-turn (symbolic) (TM5-1-Q02) panel shall **only** be used with a DETOUR panel (TM5-7A or TM5-7B).



TM5-1-Q01



TM5-1-Q02



TM5-1-Q03